



USER MANUAL

N-SERIES CONTROLLERS

N-COMMAND 2.0 CONTROL APPLICATIONS

SVSI SYSTEM CONFIGURATION MANAGEMENT

SC-N8001 (5 USERS/50 DEVICES), SC-N8002 (UNLIMITED), SC-N8012 (ENTERPRISE)



IMPORTANT SAFETY INSTRUCTIONS

1. READ these instructions.
2. KEEP these instructions.
3. HEED all warnings.
4. FOLLOW all instructions.
5. DO NOT use this apparatus near water.
6. CLEAN ONLY with dry cloth.
7. DO NOT block any ventilation openings. Install in accordance with the manufacturer's instructions.
8. DO NOT install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
9. DO NOT defeat the safety purpose of the polarized or grounding type plug. A polarized plug has two blades with one wider than the other. A grounding type plug has two blades and a third grounding prong. The wider blade or the third prong are provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
10. PROTECT the power cord from being walked on or pinched, particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
11. ONLY USE attachments/accessories specified by the manufacturer.
12. UNPLUG this apparatus during lightning storms or when unused for long periods of time.
13. REFER all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.
14. DO NOT expose this apparatus to dripping or splashing and ensure that no objects filled with liquids, such as vases, are placed on the apparatus.
15. To completely disconnect this apparatus from the AC Mains, disconnect the power supply cord plug from the AC receptacle.
16. Where the mains plug or an appliance coupler is used as the disconnect device, the disconnect device shall remain readily operable.
17. DO NOT overload wall outlets or extension cords beyond their rated capacity as this can cause electric shock or fire.
18. Elevated Operating Ambient - If installed in a closed or multi-unit rack assembly, the operating ambient temperature of the rack environment may be greater than room ambient. Therefore, consideration should be given to installing the equipment in an environment compatible with the maximum ambient temperature (T_{ma}) specified by the manufacturer.
19. Reduced Air Flow - Installation of the equipment in a rack should be such that the amount of air flow required for safe operation of the equipment is not compromised.
20. Mechanical Loading - Mounting of the equipment in the rack should be such that a hazardous condition is not achieved due to uneven mechanical loading.
21. Circuit Overloading - Consideration should be given to the connection of the equipment to the supply circuit and the effect that overloading of the circuits might have on overcurrent protection and supply wiring. Appropriate consideration of equipment nameplate ratings should be used when addressing this concern.
22. Reliable Earthing - Reliable earthing of rack-mounted equipment should be maintained. Particular attention should be given to supply connections other than direct connections to the branch circuit (e.g. use of power strips).



The exclamation point, within an equilateral triangle, is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the product.



The lightning flash with arrowhead symbol within an equilateral triangle is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electrical shock to persons.



ESD Warning: The icon to the left indicates text regarding potential danger associated with the discharge of static electricity from an outside source (such as human hands) into an integrated circuit, often resulting in damage to the circuit.

- WARNING:** To reduce the risk of fire or electrical shock, do not expose this apparatus to rain or moisture.
- WARNING:** No naked flame sources - such as candles - should be placed on the product.
- WARNING:** Equipment shall be connected to a MAINS socket outlet with a protective earthing connection.
- WARNING:** To reduce the risk of electric shock, grounding of the center pin of this plug must be maintained.

COPYRIGHT NOTICE

AMX© 2018, all rights reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted, in any form or by any means, electronic, mechanical, photocopying, recording, or otherwise, without the prior written permission of AMX. Copyright protection claimed extends to AMX hardware and software and includes all forms and matters copyrightable material and information now allowed by statutory or judicial law or herein after granted, including without limitation, material generated from the software programs which are displayed on the screen such as icons, screen display looks, etc. Reproduction or disassembly of embodied computer programs or algorithms is expressly prohibited.


LIABILITY NOTICE



No patent liability is assumed with respect to the use of information contained herein. While every precaution has been taken in the preparation of this publication, AMX assumes no responsibility for error or omissions. No liability is assumed for damages resulting from the use of the information contained herein. Further, this publication and features described herein are subject to change without notice.

AMX WARRANTY AND RETURN POLICY

The AMX Warranty and Return Policy and related documents can be viewed/downloaded at www.amx.com.

ESD WARNING

	<p>To avoid ESD (Electrostatic Discharge) damage to sensitive components, make sure you are properly grounded before touching any internal materials.</p> <p>When working with any equipment manufactured with electronic devices, proper ESD grounding procedures must be followed to make sure people, products, and tools are as free of static charges as possible. Grounding straps, conductive smocks, and conductive work mats are specifically designed for this purpose.</p> <p>Anyone performing field maintenance on AMX equipment should use an appropriate ESD field service kit complete with at least a dissipative work mat with a ground cord and a UL listed adjustable wrist strap with another ground cord</p>
---	--

  <p>CAUTION RISK OF ELECTRIC SHOCK DO NOT OPEN</p>	<p>WARNING: Do Not Open! Risk of Electrical Shock. Voltages in this equipment are hazardous to life. No user-serviceable parts inside. Refer all servicing to qualified service personnel. Qualified personnel must disconnect BOTH power supplies before servicing.</p> <p>Place the equipment near a main power supply outlet and make sure that you can easily access the power breaker switch.</p>
--	--

WARNING: This product is intended to be operated ONLY from the voltages listed on the back panel or the recommended, or included, power supply of the product. Operation from other voltages other than those indicated may cause irreversible damage to the product and void the products warranty. The use of AC Plug Adapters is cautioned because it can allow the product to be plugged into voltages in which the product was not designed to operate. If the product is equipped with a detachable power cord, use only the type provided with your product or by your local distributor and/or retailer. If you are unsure of the correct operational voltage, please contact your local distributor and/or retailer.

FCC AND CANADA EMC COMPLIANCE INFORMATION:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Approved under the verification provision of FCC Part 15 as a Class A Digital Device.

Caution: Changes or modifications not expressly approved by the manufacturer could void the user's authority to operate this device.

CAN ICES-3 (B)/NMB-3(B)

You may obtain a free copy of the Declaration of Conformity by visiting <http://www.amx.com/techcenter/certifications.asp>.

EU COMPLIANCE INFORMATION:

Eligible to bear the CE mark; Conforms to European Union Low Voltage Directive 2006/95/EC; European Union EMC Directive 2004/108/EC; European Union Restriction of Hazardous Substances Recast (RoHS2) Directive 2011/65/EU.

WEEE NOTICE:

	<p>This appliance is labeled in accordance with European Directive 2012/19/EU concerning waste of electrical and electronic equipment (WEEE). This label indicates that this product should not be disposed of with household waste. It should be deposited at an appropriate facility to enable recovery and recycling.</p>
---	--

LASER SAFETY STATEMENT

The DVD drive included in this equipment contains a laser that is compliant with IEC 60825-1, Ed. 2. 2007.

Table of Contents

Chapter 1: Introducing Your New N8000	6
Product Overview	6
Hardware Overview	7
N8001 N-Command Controller	7
N8002 N-Command Controller	7
N8012 N-Command Controller	8
Chapter 2: Installing and Configuring the N8000	9
Preparing for Install	9
Connecting the N8000 to the Network	9
Establishing Communication with the N8000	10
Logging In	10
Chapter 3: Configuration Options	11
View Options	11
Video Matrix Page	12
Audio Matrix Page	13
USB Matrix Page	15
NVR Controls Page	16
Panel Viewer Page	19
Build Options	20
Script Builder Page	21
Task Builder Page	23
Wall Builder Page	24
Third Party Page	25
Panel Builder Page	26
Admin Options	27
Unit Management Page	28
IP Addresses Page	29
System Settings Page	31
User-Groups Page	33
Logs Page	34
Master-Slave Page	35
Setup Time Page	36
Firmware Updater Page	37
Local Play Options	38
Library-Playlist Page	38
Batch Upload Page	39
Batch LP 1-to-1 Page	40
Backups Options	41
Backup Restore Page	41
Unit Migrate Page	42

Appendix A: Panel Builder Tutorial	43
Beginning a Panel Builder Project.....	43
Top Ribbon Option Descriptions	45
Project Pane Option Descriptions	47
Item Properties Tab.....	47
Panel Tab.....	48
Project Tab	49
Assets Tab.....	49
Tools Pane Option Descriptions	50
Buttons Tab.....	50
Widgets Tab	51
Templates Tab	51
Appendix B: Wall Builder Tutorial	52
Wall Builder Basics	52
Sample Configuration Using Wall Builder.....	52
Appendix C: Minimum Network Requirements	55
Appendix D: N-Command Failover Configuration	57
Introduction	57
Needed equipment.....	57
Connection Diagram	57
General Functionality.....	57
Failover Scenarios	58
Override Mechanisms	58
Setup	58
Stopping Master/Slave	61
Important Notes	61

Chapter 1: Introducing Your New N8000

Product Overview

The SC-N8000 N-Command Series of Control Applications provides intuitive and powerful management of SVSI system configuration, task automation, scripting, and wall building. SC-N8001 offers AV switching for 5 users and 50 devices, while the SC-N8002/SC-N8012 allow unlimited users and devices. N-Command Control Appliances also include a simplified ASCII interface for third-party control via TCP/IP. Basic features are listed below. See [Table 1](#) for a break-down on the features offered for each of the three N-Command control devices.

Features

- Multi-user, web-based graphical matrix displays offer easy point-and-click control distributing and switching.
- Switch Decoders to different Encoder streams using single graphical matrix.
- Tasks can be scheduled, edited, deleted, or executed immediately for content display.
- Includes wallbuilder, scripting, and panel builder features.
- Manage multiple video streams on a single Ethernet connection.
- Power Requirements: 120 Volt AC power input
- Certifications: FCC, CE, and NTRL
- Temperature: 32° to 104°F (0° to 40°C)
- Humidity: 10% to 90% RH (non-condensing)

TABLE 1 Basic Specifications

Features	SC-N8001	SC-N8002	SC-N8012
Interface	Ethernet	2xEthernet	2xEthernet
Web-Based Control	Yes	Yes	Yes
Custom Panels	Yes	Yes	Yes
Custom Scripts	Yes	Yes	Yes
Max Devices	50	Unlimited	Unlimited
Group Management	Yes	Yes	Yes
Host PC Required	No	No	No
Platform	Dedicated Hardware	Dedicated Hardware	Dedicated Hardware
Users	5 Simultaneous	Unlimited	Unlimited
Audio Matrix Control	Yes	Yes	Yes
Backup and Restore	Yes	Yes	Yes
Direct TCP	Yes	Yes	Yes
Control Third-Party Devices	Yes	Yes	Yes
Dimensions (HWD)	1.5" x 7.5" x 7.5" (3.81 x 19.05 x 3.81 cm)	3.5" x 17" x 15.5" (8.9 x 43.18 x 39.37 cm)	3.5" x 17.5" x 18" (8.9 x 44.45 x 45.72 cm)
Weight	2 lbs (0.9 kg)	19 lbs (8.61 kg)	30 lbs (13.61 kg)

Hardware Overview

N8001 N-Command Controller

Refer to [Figure 1](#) as well as the [Front and Rear Panel Descriptions table](#) on page 8 for hardware details on the N8001 N-Command Controller.




FIG. 1 N8001 Front and Rear Panel

N8002 N-Command Controller

The N8002 is built from a standard computer, but not all buttons, LEDs, and connectors are enabled. Refer to [Figure 2](#) as well as the [Front and Rear Panel Descriptions table](#) on page 8 for hardware details on the N8002 N-Command Controller.




FIG. 2 N8002 Front and Rear Panel

N8012 N-Command Controller

The N8012 is built from a standard computer, but not all buttons, LEDs, and connectors are enabled. Refer to [Figure 3](#) as well as the [Front and Rear Panel Descriptions table](#) on page 8 for hardware details on the N8012 N-Command Controller.




FIG. 3 N8012 Front and Rear Panel

TABLE 2 Front and Rear Panel Descriptions

Front Panel	
ON/OFF button	Press to turn unit on or off.
POWER indicator	For the N8001, the power button illuminates green when power is on. For the N8002/N8012 the power LED turns solid (blue) when power is on.
HDD LED	On flashing (red) when there is software activity. (N8002 only.)
Solid-State Hard Drives	Three 128 GB solid-state hard drives that are configured in a raid configuration, allowing for swapping in the event of failure. (N8012 only.)
Rear Panel	
RJ-45 ports - One on the N8001 - Two on the N8002 and N8012	ETH 0 (N8002, N8012): 8-wire RJ45 female. 10/100/1000 Mbps 10/100/1000Base-T auto-sensing gigabit Ethernet switch port. Can be used to connect to a separate corporate LAN. ETH 1 (N8001, N8002, N8012): 8-wire RJ45 female. 10/100/1000 Mbps 10/100/1000Base-T auto-sensing gigabit Ethernet switch port. Must be connected to the network in order to provide device and user control.
Power Input	N8001: Comes with an AC power brick. Input is 120V - 240V. Output is 12V/5A. N8002/N8012: 120 Volt AC power input for external power supply.
Power On/Off Switch	Use to apply or remove power to the unit from the power supply (N8002 only). NOTE: This On/Off switch should only be used to disconnect the N8002 from main power once it has been properly shut down. Use the on/off button on the front of the unit for proper shut down.

Chapter 2: Installing and Configuring the N8000

Preparing for Install

This chapter provides step-by-step guidance for installing and configuring equipment from the N-Series product family on your network. The steps provided here assume the following to be true:

1. *There are switches operational on the network.*
N-Series equipment can operate on many different brands of networking equipment. The network itself needs to meet certain requirements to be able to support deployment. These instructions assume that you have purchased and installed a pre-configured switch from AMX or that your existing equipment meets the following physical and protocol requirements:
 - Layer 2 via IGMP and Layer 3 through PIM (Protocol Independent Multicast)
 - Gigabit Ethernet
 - IGMP Snooping
 - IGMP Snooping Querier

NOTE: To proceed with this installation, the switches must already be successfully connected to your network. If needed, refer to your product's documentation for installation instructions.

2. *Deployment considerations have been made for the addition of high-speed video.*
Our Networked AV solutions provide unsurpassed video and audio quality at bandwidths appropriate to any network segment or link. Matrix switches as large as 1200x800 have been constructed on a house network using N-Series equipment. Alternatively, many customers choose to deploy on physically separate networks in order to use low-cost network appliances but keep video traffic separate from data and voice.

NOTE: For a more detailed requirements list, refer to [Appendix C: Minimum Network Requirements on page 55](#).

NOTE: N-able and N-Command products include software developed by the OpenSSL Project for use in the OpenSSL Toolkit (<http://www.openssl.org/>).

Step 1: Connecting the N8000 to the Network

The SC-N8001 only requires the included power adapter and a single network connection (to the LAN port) to allow up to five users to simultaneously configure, set-up, and control as many as 50 Networked AV devices. The SC-N8002 and SC-N8012 require a network connection to the Eth 1 port in order to control unlimited devices with unlimited users. Eth 0 is used for separate corporate LAN. See [Figure 4](#) for an example showing the N8002.

Step 1: Using Cat-5 cable, connect the N8002's RJ-45 ETH 1 port (the right-most port) to the Network Switch.

Step 2: Using the external power supply provided in shipment, connect the unit to power source.

Step 3: Toggle switch to the on position.




FIG. 4 CONNECTING N8002 TO THE NETWORK

NOTE: On the N8002 and N8012, there are two Ethernet ports (ETH 0 and ETH 1). ETH 0 (on the left) is used for an optional connection to a separate corporate LAN. ETH 1 (on the right) must be connected to the network to provide device and user control.

Step 2: Establishing Communication with the N8000

Each controller ships with dual IP addresses (192.168.1.99 with a netmask of 255.255.255.0 and 169.254.10.99 with a netmask of 255.255.0.0).

- **For the single Ethernet port of the N8001:**
The single **Eth1** port is assigned both IP addresses.
- **For the two Ethernet ports of the N8002/N8012:**
Eth0 gets the 192 address and should be used as the outward-facing IP address for LAN or WAN control. The 169 address (assigned to **Eth1**) is in the default IP address range with which all N-Series Encoders and Decoders are shipped.

Logging In

The N-Command Controller has a web-based interface. To access the interface, open a web browser and navigate to the unit's IP address. Google Chrome is the recommended browser.

- After applying power to the unit, allow approximately one minute for initialization.
- Once the unit boots, enter **192.168.1.99** into your web browser's URL bar.
- The device log-in page displays. Enter the default username (**admin**) and password (**password**). These can be changed after initial login.
- After successful login, click on the **Admin > Unit Management** drop-down menu to discover all networked AV devices on the video network.
- These units display on the **Matrix** page. The login IP address can be changed by going to **Admin > IP Address**.

NOTE: The N8000 Software is based in part on the work of the Independent JPEG Group.

NOTE: This product includes software developed by the OpenSSL Project for use in the OpenSSL Toolkit (<http://www.openssl.org/>).

From any main page in the web interface, you can access all other main pages by clicking the links in the top navigation bar.




FIG. 5 VIEW VIDEO PAGE

NOTE: Screen-by-screen descriptions of the web interface options are provided for your reference in [Chapter 3: Configuration Options on page 11](#).

These units function as a virtual matrix switch for N-Series Encoders/Decoders and serve as a touch-panel editor for easy graphical control of networked AV installations.

Chapter 3: Configuration Options

This chapter defines N-Command's configuration options. For ease of navigation, it is organized to reflect the graphical user interface (GUI). From any main page in the GUI, you can access all other main sections by clicking the links in the top navigation bar. [Figure 6](#) shows the navigation bar and provides hot links to the sections of this chapter which describe each main section.




FIG. 6 Section Links

View Options

Click the **View** link at the top of any of the main web pages to access the options shown in [Figure 7](#). Refer to the following sections for detailed descriptions:

- [Video Matrix Page on page 12](#)
- [Audio Matrix Page on page 13](#)
- [USB Matrix Page on page 15](#)
- [NVR Controls Page on page 16](#)
- [Panel Viewer Page on page 19](#)

Click here to access the **View** options.




FIG. 7 Choosing View

Video Matrix Page

Click **View > Video Matrix** to access the page shown in [Figure 8](#). This page displays all discovered devices on your network. Encoders are listed horizontally across the top of the page while Decoders are listed vertically down the left side. Clicking a unit's name takes you to the configuration pages for that device.

Use this page to route video from an Encoder to a Decoder by simply clicking the circle in their common cell on the matrix. If the two units are not compatible, there will be no circle in that cell. The circle's color provides you with current connection information. For example:

- *White* circles signify an active connection.
- *Gray* circles signify that the two units are available for connection (i.e., compatible with each other).
- *Dark Red* circles signify that the two units are compatible with each other, but one of them is offline.
- *Light Red* circles signify that the two units have an active connection, but one of them is offline.

Options are described in [Table 3](#).




FIG. 8 Viewing Video Equipment

TABLE 3 Video Matrix Page Option Descriptions

Option	Description	Notes
All	Click the circle in the Encoder's ALL cell to connect all compatible streams to that Encoder.	This triggers N-Command to send a command to all compatible Decoders to switch to that one Encoder.
Hide inactive checkbox	Enable to hide any discovered units that are currently not communicating (off-line).	

TABLE 3 Video Matrix Page Option Descriptions (Cont.)

Option	Description	Notes
Hide NVR checkbox	Enable to hide all discovered N6123 Network Video Recorders on this network.	
Launch Script drop-down	Choose a script to launch from the drop-down menu. Scripts are created using the Script Builder .	See Script Builder Page on page 21 for more information.
All Units drop-down	If you have created any User-Groups , they will be available for selection in this drop-down menu. Once a group is selected, only the units in that group are displayed in the matrix.	See User-Groups Page on page 33 for more information.
Cancel button	Click to cancel any pending changes.	
Take button	Click to accept changes made on this page.	

Audio Matrix Page

Click **View > Audio Matrix** to access the page shown in [Figure 9](#). This page displays all discovered devices (Decoders, Encoders, NVRs, ATRs, etc.) on your network. Encoders/transmit streams are listed horizontally across the top of the page while Decoders/receive streams are listed vertically down the left side. Use this page to route audio from one device to another by simply clicking the common cell on the matrix, followed by clicking the **Take** button. Clicking a unit's name takes you to the configuration pages for that device.

You can route any N-Series Encoder to any N-Series Decoder. For example, you can route the audio from an N1000 Encoder to an N2235 Decoder. This is why all the cells show as being common (represented by gray circles). Options are described in [Table 4](#).


**FIG. 9** Viewing Audio Equipment

TABLE 4 Audio Matrix Page Option Descriptions

Option	Description	Notes
All	Click the circle in the Encoder's ALL cell to connect all compatible streams to that Encoder.	This triggers N-Command to send a command to all compatible Decoders to switch to that one Encoder.
Hide inactive checkbox	Enable to hide any discovered units that are currently not communicating (off-line).	
Hide NVR checkbox	Enable to hide all discovered N6123 Network Video Recorders on this network.	
Launch Script drop-down	Choose a script to launch from the drop-down menu. Scripts are created using the Script Builder .	See Script Builder Page on page 21 for more information.
All Units drop-down	If you have created any User-Groups , they will be available for selection in this drop-down menu. Once a group is selected, only the units in that group are displayed in the matrix.	See User-Groups Page on page 33 for more information.
Cancel button	Click to cancel any pending changes.	
Take button	Click to accept changes made on this page.	

USB Matrix Page

Click **View> USB Matrix** to access the page shown in [Figure 10](#). This page displays all discovered devices on your network which feature USB support. Encoders are listed horizontally across the top of the page while Decoders are listed vertically down the left side. Use this page to route which Encoder the Decoder's KVM is connected to by simply clicking the common cell on the matrix, followed by clicking the **Take** button. Clicking a unit's name takes you to the configuration pages for that device. Options are described in [Table 5](#).



FIG. 10 Viewing Equipment with USB Support

TABLE 5 USB Matrix Page Option Descriptions

Option	Description	Notes
Hide inactive checkbox	Enable to hide any discovered units that are currently not communicating (off-line).	
Hide NVR checkbox	Enable to hide all discovered N6123 Network Video Recorders on this network.	
Launch Script drop-down	Choose a script to launch from the drop-down menu. Scripts are created using the Script Builder .	See Script Builder Page on page 21 for more information.
All Units drop-down	If you have created any User-Groups , they will be available for selection in this drop-down menu. Once a group is selected, only the units in that group are displayed in the matrix.	See User-Groups Page on page 33 for more information.
Cancel button	Click to cancel any pending changes.	
Take button	Click to accept changes made on this page.	

NVR Controls Page

Click **View > NVR Controls** to access the page shown in [Figure 11](#). Options are described in [Table 6](#).




FIG. 11 NVR Controls Page

TABLE 6 NVR Controls Option Descriptions

Option	Description	Notes
NVR drop-down	Select an NVR from the list of discovered NVRs on your network.	
Mode drop-down	Select the NVR mode (N1000, N2000, N2400, N3000).	
Playback drop-down	Select a recorded file stored on the selected NVR to play back.	
Channel drop-down	Select which stream to use for recording playback.	
Loop checkbox	Enable this option to place the recording you are playing back in a continuous loop (so it constantly repeats).	
Playback controls	Use these controls to start/stop/pause/navigate the recording.	
Recording link	Refer to Recording Settings on page 17 for details on the options available from this link.	
NVR Copy link	Refer to NVR Copy Settings on page 18 for details on the options available from this link.	
MPEG link	Refer to MPEG Settings on page 18 for details on the options available from this link.	

Recording Settings

The section of the **NVR Controls** page shown in [Figure 12](#) is displayed when you click the **Recording** link. Options are described in [Table 7](#).

FIG. 12 Recording Settings

TABLE 7 NVR Controls Page: Recording Settings

Option	Description	Notes
Description field	Enter a description for this recording.	
Time (min) field	Limit recording time by entering a duration (in minutes).	How this limit is enforced depends on whether or not the Continuous checkbox is enabled.
Record Vid	Choose from a list of compatible Encoders to choose to record from.	These fields are dependent on the chosen Mode . The number of record stream numbers listed depends on which series is selected. The N1000, N2000, and N2400 series each have one recording channel. The N1000's recording channel can only record one stream, whereas the N2000 can record two streams on that one channel (dual recording). The N3000 has ten recording channels, and each channel can only record one stream.
Channel field	Select which channel/stream to record from.	This selection is dependent on which Mode you are in (i.e., which series you are recording from). <ul style="list-style-type: none"> • In N1000 mode, this field is not applicable. • In N2000 mode, you can select 1 for channel 1 or dual to record both streams. • In N3000 mode, there will be ten different channels to select.
Continuous checkbox	Enable if you would like the recording to continue beyond the Time entered.	<ul style="list-style-type: none"> • If Continuous is not enabled, the recording will simply end after the Time entered has been reached (see the Time field description earlier in this chapter). • If Continuous is enabled, the NVR will continue recording after the Time entered. However, it will only create a recording matching the designated length of time. In other words, if Time is set to 10 minutes and the recording continues for 40 minutes, you will only capture the last 10 minutes of that recording.
Convert checkbox	Enable if you want a conversion to take place automatically once the recording is complete.	
Bitrate drop-down	Leave the bitrate at the recommended setting or adjust as needed.	The higher the bitrate, the higher the quality (and the larger the file) of the conversion. The default is 7500 kbps.
Record button	Click to begin recording using the current settings.	
Stop Record button	Click to end the recording.	

NVR Copy Settings

The section of the **NVR Controls** page shown in [Figure 13](#) is displayed when you click the **NVR Copy** link. Options are described in [Table 8](#).




FIG. 13 NVR Copy Settings

TABLE 8 NVR Controls Page: NVR Copy Settings

Option	Description	Notes
Destination NVR drop-down	Choose to copy a recording from the NVR selected at the top of the NVR Controls page to the NVR selected as the Destination NVR .	
Recording drop-down	Choose which recording you wish to copy.	
Copy button	Click to begin copying the recording.	

MPEG Settings

The section of the **NVR Controls** page shown in [Figure 14](#) is displayed when you click the **MPEG** link. Options are described in [Table 9](#).




FIG. 14 MPEG Settings

TABLE 9 NVR Controls Page: MPEG Settings

Option	Description	Notes
Recording drop-down	Select a recording to convert to an MPEG file.	
Bitrate drop-down	Leave the bitrate at the recommended setting or adjust as needed.	The higher the bitrate, the higher the quality (and the larger the file) of the conversion.
Convert button	Click to begin the conversion.	
MPEG List	Completed conversions are listed here.	
Stop converting button	Click to end the conversion.	
Delete button	Click to delete the MPEG file selected in the MPEG List.	
Download mpeg button	Select a conversion from the list and then click this button to download the file.	

Panel Viewer Page

Click **View > Panel Viewer** link to access the page shown in [Figure 15](#). Options are described in [Table 10](#).




FIG. 15 Panel Viewer Page

TABLE 10 Panel Viewer Option Descriptions

Option	Description	Notes
Panels list	Lists any panels that are saved on N-Command (through Panel Builder).	
Launch Panel button	Click to launch a window with a preview of the selected panel in it.	This launches just a preview of the panel. You can click on buttons but cannot edit the panel.

Build Options

Click the **Build** link at the top of any of the main web pages to access the options shown in [Figure 16](#). Refer to the following sections for detailed descriptions:

- [Script Builder Page on page 21](#)
- [Task Builder Page on page 23](#)
- [Wall Builder Page on page 24](#)
- [Third Party Page on page 25](#)
- [Panel Builder Page on page 26](#)

Click here to access
the **Build** options.



FIG. 16 Choosing Build

Script Builder Page

Click **Build > Script Builder** to access the page shown in [Figure 17](#). Scripts are programs you write to use over and over again. For example, you could create scripts that shut all equipment down for the evening, putting your Encoders and Decoders in lower power mode, turning off all TVs and lights, etc. A predefined set of commands could be created here. Basically, anything that can be controlled with TCP commands can be controlled in this script. There are also predefined actions that you can choose (no programming knowledge needed). Options are described in [Table 11](#).

NOTE: Script commands are accessible via TCP port 50020 and SSL port 50120.



FIG. 17 Script Builder Page

TABLE 11 Script Builder Option Descriptions

Option	Description	Notes
Script selection drop-down	Select an existing script to load. This list shows all scripts that were already created and saved on this unit.	Scripts are displayed in the format: "Script ID":"Name of script"
Load button	Click to load the script selected from the drop-down (described previously).	
Delete button	Click to delete the selected script.	

TABLE 11 Script Builder Option Descriptions (Cont.)

Option	Description	Notes
Import button	Click to import a script.	
Export button	Click to export a script.	Scripts export as JSON (a standard human-readable serialized format).
Tools icon	Here you can select if the scripts are created with the IP address, the MAC address, or the name of the unit.	
Name field	Enter a name for the script you are creating.	
Action list	Pick the command you want it to do	The selections to the right of the Action box change based on what unit type is affected by the action. Misc commands are used often. You generate the command and then edit the command as you need for your purposes. This works with third party equipment as well (anything with an IP address and port number).
Save button	Click to save changes made to this page.	
Save As button	Click to save the changes you made under a new script name.	
Execute Script button	Click to launch the selected script.	

Task Builder Page

Click **Build > Task Builder** to access the page shown in [Figure 18](#). After you have created scripts (as discussed previously in the [Script Builder Page on page 21](#)) use **Task Builder** to schedule when those scripts will be executed. Click on a day to schedule a task. Options are described in [Table 12](#).




FIG. 18 Task Builder Page

TABLE 12 Task Builder Option Descriptions

Option	Description	Notes
New Task button	Click to add a new task to the selected day.	
Search field	Enter the name of a script to search.	This searches every field in the table, including tasks and script names.

Wall Builder Page

Click **Build > Wall Builder** to access the page shown in [Figure 19](#). Refer to [Appendix B: Wall Builder Tutorial on page 52](#) for details on this feature.

Wall Settings

☒ N2k Decoders

☐ N1k Decoders

☐ Windowing Processors

☐ 4K Decoders

Wall Name

Wall Name

Size

2

Rows

2

Columns

Output Mode

☒ 1080p

☐ 720p

☐ 4K

Coordinates are from top left to bottom right.

Unit 0,0

Unit IP

×

Unit 0,1

Unit IP

×

Unit 1,0

Unit IP

×

Unit 1,1

Unit IP

×

Use Temp Values

Save

Close

FIG. 19 Wall Builder Page

Third Party Page

Click **Build > Third Party** to access the page shown in [Figure 20](#). Options are described in [Table 13](#). Here you can add information about your third party system. This information then populates within **Panel Builder** and **Script Builder**. For example, if you know you are going to be controlling a certain brand of television, you can enter the model information here and then re-use that information in **Panel Builder** and **Script Builder**.




FIG. 20 Third Party Page

TABLE 13 Third Party Option Descriptions

Option	Description	Notes
New Command button	Click to begin addition of a new third party related command.	
Choose File button	Click to browse to a CSV file to upload.	
Import button	Click to import the selected CSV file.	
Download CSV link	Click to export a CSV file for editing.	This CSV is for third-party commands only. N-Command has a special CSV format for third-party command entries.
Search field	Search for devices in the list (by name, type, etc.).	

Panel Builder Page

Click **Build > Panel Builder** to access the page shown in [Figure 21](#). Panel Builder is a GUI application that allows you to create custom panels to be used as a standalone control option or as an extension to a third-party control system. Using **Panel Builder**, you can generate panels for display on any mobile device or PC/Mac. Refer to [Appendix A: Panel Builder Tutorial on page 43](#) for details on this feature.




FIG. 21 Panel Builder Page

Admin Options

Click the **Admin** link at the top of any of the main web pages to access the options shown in [Figure 22](#). Refer to the following sections for detailed descriptions:

- [Unit Management Page on page 28](#)
- [IP Addresses Page on page 29](#)
- [System Settings Page on page 31](#)
- [User-Groups Page on page 33](#)
- [Logs Page on page 34](#)
- [Master-Slave Page on page 35](#)
- [Setup Time Page on page 36](#)
- [Firmware Updater Page on page 37](#)

Click here to access
the **Admin** options.




FIG. 22 Choosing Admin

Unit Management Page

Click **Admin > Unit Management** to access the page shown in [Figure 23](#). Options are described in [Table 14](#).




FIG. 23 Unit Management Page

TABLE 14 Unit Management Option Descriptions

Option	Description	Notes
Auto Discover/Discover Units button	If this button says Auto Discover , then N-Command is scanning periodically for new units. If it says Discover Units , click to search for newly-added units on the network.	
Discovery is Enabled/Disabled	If this button says Discovery is Enabled then N-Command can discover units on the network. Click to change to Discovery is Disabled at which point N-Command will no longer discover units on the network.	
Remove Selected	Click to remove all selected units from the Unit Management page display.	Removes the selected unit from the list of units discovered by N-Command.
Remove All Offline	Click to remove all inactive units from the Unit Management page display.	Removes any units in the list that are offline/not communicating.
Add by IP	Click to search for and add a unit by its IP address.	
Import CSV	Click to select a CSV file to import for batch configuration.	
Export CSV	Click to export the CSV file for editing.	
Select All button	Click to select all units in the list.	
Select None button	Click to clear out any selections.	
Search field	Search for a unit on the network by name, IP address, stream, etc.	Anything listed in the column headings of this page can be used as a search term (e.g., Name, Type, SN, etc.).

IP Addresses Page

Click **Admin > IP Addresses** to access the page shown in [Figure 24](#). Options are described in [Table 15](#).

AMX

View

Build

Admin

Local Play

Backups

Help

Unit ManagementIP AddressesSystem SettingsUser-GroupsLogs

Ethernet Interface 0

IP Mode:

static

Static IP

MAC address

00:19:0B:0F:03:2B

IP address

192.168.1.224

192.168.1.224

Ping

Netmask

255.255.255.0

255.255.255.0

Static 2nd address

disabled

Disable

IP address

Ping

Netmask

Static 3rd (master/slave) enabled

Enable

IP address

172.21.10.224

172.21.10.224

Ping

Netmask

255.255.255.0

255.255.255.0

Ethernet Interface 1

IP Mode:

static

Static IP

MAC address

00:19:0B:0F:03:2C

IP address

169.254.10.242

169.254.10.242

Ping

Netmask

255.255.0.0

255.255.0.0

Static 2nd address

disabled

Disable

IP address

Ping

Netmask

Static 3rd (master/slave) enabled

Enable

IP address

192.168.2.224

192.168.2.224

Ping

Netmask

255.255.255.0

255.255.255.0

Gateway 192.168.1.1

192.168.1.1

Ping

DNS Servers

DNS1 address 8.8.8.8

8.8.8.8

DNS2 address 8.8.4.4

8.8.4.4

DNS3 address

Cancel Changes

Save Changes

FIG. 24 IP Addresses Page

TABLE 15 IP Addresses Option Descriptions

Option	Description	Notes
IP Mode	Choose Static IP or Disable . When set to Static IP , an IP address, Netmask, and Gateway address must be manually entered.	
MAC address	View the MAC addresses for the Ethernet interface.	
IP address	View/edit the current IP address of the N8000 unit's Ethernet interfaces.	
Netmask	View/edit the current Netmask for the N8000 unit's interfaces.	
Static address	Add second and/or third Static IP addresses.	<p>These are general purpose IP addresses. Complicated networks sometimes need multiple IP addresses on N-Command. It is not used often.</p> <p>Static 3rd is used for master/slave setup. If master/slave is not needed, it can instead be used by a third general purpose IP address.</p>
Gateway	View the current Gateway address for the N8000 unit's Ethernet interfaces. When in Static IP mode, you may enter a new Gateway address into this field.	
DNS Servers	DNS server settings are required to reach domain names on the Internet (such as when using an Internet NTP service).	
Ping	The Ping links allow you to test connectivity.	
Cancel Changes button	Click to return all controls to the last saved configuration.	
Save Changes button	Click to save changes made to this page.	

System Settings Page

Click **Admin > System Settings** to access the page shown in [Figure 25](#). Options are described in [Table 16](#).

AMX

View

Build

Admin

Local Play

Backups

Help

Unit ManagementIP AddressesSystem SettingsUser-GroupsLogsMaster

System Settings

Device Name

00-19-0B-0F-03-2C

Auto-login Username

Change username

Auto-login Password

Change password

Enable LDAP:

☒ Enable

Server Domain:

192.168.1.20

Ping

AD Name:

WINLDAPVM

LDAP Guests:

☒ Allow Access to LDAP Group

Save

Unsolicited Unit Status

These are not sending a status to eth1 (169.254.10.242) when modified by other controllers.

DVR:N6123 DVR 4K60
N1-DEC-KVM-2251_DEC_1
N1-DEC-KVM-2251_DEC_2
N1-ENC-KVM-2151_ENC_1
N1-ENC-KVM-2151_ENC_2
NCMD:best.ncmd.2
DVR-Dan Office NVR
N1-DEC-00-19-0B-80-05-52
NCMD:NCmd2_36
N1-ENC-HD-SDI-ENC_1_MPC

Assign to 169.254.10.242

Netlinx Settings

Enable

☒

Device Status:

Online

Master Mode:

Auto

IP/URL

192.168.1.162

Port

1319

Device Number

8002

System Number

10

Username

admin

Password

Save

FIG. 25 System Settings Page

TABLE 16 System Settings Option Descriptions

Option	Description	Notes
Device Name	Enter a user-friendly name for the unit.	More descriptive names in this field help you organize and manage the N-Series system efficiently. Names based on the unit's location and function are very useful.
Auto-login Username	In most cases, leave at default setting (admin).	Mostly for use with legacy products. If a unit does not support self-hosted web pages, N-Command will try to log in to display the web page using the given username and password.

TABLE 16 System Settings Option Descriptions (Cont.)

Option	Description	Notes
Auto-login Password	In most cases, leave at default setting (password).	Mostly for use with legacy products. If a unit does not support self-hosted web pages, N-Command will try to log in to display the web page using the given username and password.
Enable LDAP	Enable to configure the unit to access the network's LDAP (lightweight directory access protocol) services.	
Server Domain	Enter the IP address of the LDAP server.	
AD Name	Enter the Active Directory's name.	
LDAP Guests	Enable to allow guest access to LDAP through N-Command.	If enabled, this allows base-level users with guest credentials to access certain systems through N-Command.
Save button	Click to save setting made to this section.	
Unsolicited Unit Status section	Devices in this list are not configured to send periodic status packets to this N-Command unit. To enable a device to begin sending unsolicited status packets, select it in the list and then click the Assign to... button on the right.	
Enable Netlinx Settings checkbox	Click to enable/disable NetLinx on this device.	
Device Status	This status field will show the device to be Online , Connected , Offline , or Unknown .	
Master Mode dropdown	Select Auto , Listen , or URL .	
IP/URL field	Enter the address of the Master Controller.	
Port	This field should always be set to 1319 .	
Device Number	Defaults to a dynamic device number. May be set to a static range (e.g., 8000).	
System Number	Determines which system to connect. This setting is dependent upon the Master Mode selected (see above). <ul style="list-style-type: none"> • If Master Mode is set to Auto, the System Number is set and the system discovers the Master Controller's IP address. • If Master Mode is set to Listen, the device connects to any Master Controller. • If Master Mode is set to URL, the IP of the Master Controller is set. 	
Username	Username for the Master Controller.	
Password	Password for the Master Controller.	
Save button	Click to save settings made on this page.	

User-Groups Page

Click **Admin > User Groups** to access the page shown in [Figure 26](#). You can control permissions in the network here based on user names assigned to user groups. Options are described in [Table 17](#).




FIG. 26 User-Groups Page

TABLE 17 User-Groups Option Descriptions

Option	Description	Notes
Users section	Use to create a user's account and grant them either full admin access or limited access.	
Groups section	Use to create a group and associate users/units inside a group.	Place a user into a group with certain units. If that user logs in, they will only be able to see those units.

Logs Page

Click **Admin > Logs** to access the page shown in [Figure 27](#). Options are described in [Table 18](#).

Provides information on task/script executions and shows system configuration errors (e.g., duplicate IP addresses, duplicate streams, etc.).

Clear Logs

There are no duplicate streams.

There are no duplicate IPs.

There are 5 offline units.

Messages

data	date	message	requester
Found new unit: N6123 DVR 4K60	2017-09-27 10:16:29 AM	1	ncmd
Found new unit: N4k Test Decoder 3	2017-09-27 10:12:41 AM	1	ncmd
Found new unit: COM 2251	2017-09-27 10:12:36 AM	1	ncmd
Found new unit: 00:19:0B:80:29:4E	2017-09-27 10:00:38 AM	1	ncmd
Found new unit: 00:19:0B:80:28:B5	2017-09-27 10:00:33 AM	1	ncmd
Found new unit: best ncmd 2	2017-09-27 09:45:04 AM	1	ncmd
Found new unit: Dan Office NVR	2017-09-27 09:45:00 AM	1	ncmd
Found new unit: 00:19:0B:80:05:52	2017-09-27 09:44:59 AM	1	ncmd
Found new unit: NCmd2 .36	2017-09-27 09:44:58 AM	1	ncmd
Found new unit: HD-SDI ENC 1_MPC	2017-09-27 09:44:56 AM	1	ncmd
removeallred	2017-09-27 09:42:52 AM	1	ncmd
masterslave:mode:unassigned	2017-09-27 09:41:13 AM	1	ncmd
N-Command IP addresses configured.	2017-09-27 08:53:19 AM	1	ncmd
N-Command IP addresses configured.	2017-09-27 08:29:19 AM	1	ncmd

Scripts

command	date	error	requester	scriptcmd	verbose
masterslave:mode:unassigned	2017-09-27 09:41:13 AM		127.0.0.1	1	

Tasks

There are no task logs

Server Variables

There are no server variables

Network

There are no network logs

Connected Clients

Connected client(s):
IP:127.0.0.1 PORT:48914 TIME(s):0

FIG. 27 Logs Page

TABLE 18 Logs Option Descriptions

Option	Description	Notes
Clear Logs button	Click to clear all logs listed on this page.	
Messages	View current system messages.	
Scripts	View current script logs.	
Tasks	View current task logs.	
Server Variables	View current server variables.	
Network	View current network logs.	
Connected Client(s)	View client(s) IP address, port number, and time (in seconds) that the connection has been active.	

Master-Slave Page

Click **Admin > Master-Slave** to access the page shown in [Figure 28](#). These settings allow you to create paths between two N8000 devices in case the primary (master) device fails. If the master fails, the assigned slave can take over and continue with operations until the master comes back on-line. Refer to [Appendix D: N-Command Failover Configuration on page 57](#) for more details.




FIG. 28 Master-Slave Page

Setup Time Page

Click **Admin > Setup Time** to access the page shown in [Figure 29](#). Use this section to specify Network Time Protocol (NTP) servers or to manually set time. Options are described in [Table 19](#).



FIG. 29 Setup Time Page

TABLE 19 Setup Time Option Descriptions

Option	Description	Notes
Enter NTP Servers fields	Specify up to three NTP servers.	
Sync Time button	Syncs the current time with the NTP servers.	
Manually Set Time fields	Manually enter date and time.	
Set Time button	Click to accept date/time settings.	
Time Zone drop-down	Choose a time zone.	
Save Changes button	Click to save changes made to this page.	

Firmware Updater Page

Click **Admin > Firmware Updater** to access the page shown in [Figure 30](#). Use this page for batch firmware upgrades on managed units. Once you upload the updater zip package, select the update in the list. Then select the units you want to update. The color-coded legend appears when you select the update.




FIG. 30 Firmware Updater Page

Local Play Options

Click the **Local Play** link at the top of any of the main web pages to access the options shown in [Figure 31](#). Refer to the following sections for detailed descriptions:

- [Library-Playlist Page on page 38](#)
- [Batch Upload Page on page 39](#)
- [Batch LP 1-to-1 Page on page 40](#)

Click here to access the **Local Play** options.




FIG. 31 Choosing Local Play

Library-Playlist Page

Click **Local Play > Library-Playlist** to access the page shown in [Figure 32](#). Here you can create custom playlists of selected images. These playlists can then be assigned to multiple units (using the [Batch Upload Page on page 39](#)). The units use their assigned playlists whenever they are in **Local Play/Host Play** mode. Options are described in [Table 21](#).




FIG. 32 Library-Playlist Page

TABLE 21 Library-Playlist Option Descriptions


Option	Description	Notes
Choose Files button	Browse to an image file to upload. Upload images using this button.	
Upload button	Upload the selected image file.	This feature allows you to upload an image once and then use it for multiple units being managed by this N8000 device.
Delete Selected button	Click to delete the selected image file.	
Arrow buttons	Add images to a playlist by highlighting the image from the left side, then clicking the right arrow. Remove images from a playlist by highlighting them on the playlist and clicking the left arrow	
Playlist Manager	Use the dropdown to select any already made playlists and then click the Load button.	Use to view a list or to edit by removing/adding images.

TABLE 21 Library-Playlist Option Descriptions

Option	Description	Notes
Delete List button	Click to delete the list selected in the Playlist Manager section.	
Save New button	Click to save the changes you made under a new list name.	
Save button	Click to save the changes you made under the current list name.	

Batch Upload Page

Click **Local Play > Batch Upload** to access the page shown in [Figure 33](#). Options are described in [Table 22](#).

**FIG. 33** Batch Upload**TABLE 22** Batch Upload Option Descriptions

Option	Description	Notes
Library Playlist drop-down	Choose a playlist to upload to the selected unit(s). This list includes playlists created on the Library-Playlist page (described on page 38).	Select multiple units by holding the <CTRL> key.
Decoder Playlist drop-down	Choose the playlist (on the unit) to which the chosen Library Playlist will be assigned.	This overwrites any existing playlist on the unit with that name.
Keep Aspect checkbox	Enable to lock in the aspect ratio of the given image when displaying.	
Background Fill Color	Customize the background color (used behind HostPlay images that do not take up the entire screen).	
Hold Time drop-down	Select how long each image in the playlist is displayed.	
Video Mode drop-down	Choose video mode for the playlist.	
Upload to Units button	Click to begin uploading the playlist to the selected units.	

Batch LP 1-to-1 Page

Click **Local Play** > **Batch LP 1-to-1** to access the page shown in [Figure 34](#). Use this page to send a single image to the selected units by following the steps below.

1. Highlight the desired image from the **Available Images** box.
2. Highlight the desired units and click the right arrow.
3. Select the **Playlist** to upload this image to.
4. Select the **Mode**.
5. Click **Start Batch** button to begin the process.




FIG. 34 Batch LP 1-to-1 Page

Backups Options

Click the **Backups** link at the top of any of the main web pages to access the options shown in [Figure 35](#). Refer to the following sections for detailed descriptions:

- [Backup Restore Page on page 41](#)
- [Unit Migrate Page on page 42](#)




FIG. 35 Choosing Backups

Backup Restore Page

Click **Backups > Backup-Restore** to access the page shown in [Figure 36](#). Use this page to create a backup of all data (including **Panel Builder**) with the exception of the **Local Play** library and unit backups. This can later be used to restore those portions of N-Command. Options are described in [Table 23](#).




FIG. 36 Backup-Restore Page

TABLE 23 Backup-Restore Option Descriptions

Option	Description	Notes
New Encrypted Backup button	Click to create a backup file.	
Choose File	Click to choose the selected file for use in backing up N-Command.	To use one of the listed backups, click on it to download it locally on your computer, then upload using the Choose File box.
Restore Backup	Click to begin restoring N-Command.	
File list	All backup files are listed here. Use the checkboxes to select a file to delete.	
Delete Selected	Delete all selected files.	

Unit Migrate Page

Click **Backups > Unit Migrate** to access the page shown in [Figure 37](#). These settings allow you to set up relationships between units being managed by N-Command in which if one unit goes down, that unit’s settings are transferred to another designated unit. Options are described in [Table 24](#).




FIG. 37 Unit Migrate Page

TABLE 24 Unit Migrate Option Descriptions

Option	Description	Notes
Remove unattached button	Click to remove the archived settings of units not currently in database.	
Remove all button	Click to remove the archived settings for all units.	
From/To drop-downs	Choose the unit you wish to backup in case it fails.	
Begin Migration button	Choose a backup unit.	

Appendix A: Panel Builder Tutorial

Panel Builder allows you to design attractive, intuitive, and easy-to-use touch panel layouts for controlling SVSI's Networked AV Systems and third-party equipment. **Panel Builder** provides an easy way to design a panel to control any room or facility with just a few simple steps. You can choose to use button and widget libraries that are part of Panel Builder, or import your own images to customize the panel to look exactly as you want.

The following sections explore the **Panel Builder** user interface, defining each option for easy reference. For more step-by-step project building instructions, refer to the tutorials provided in **Panel Builder's Help** menu (see *Top Ribbon Option Descriptions* section on page 45).

NOTE: *Panel Builder is accessible through N-Touch (as discussed in this document), through N-Command (N8001/N8002/N8012 web-based controllers), and also through a stand-alone version that installs directly on your computer.*

Beginning a Panel Builder Project

Follow these steps to begin a project in **Panel Builder** and explore the options provided in the **Project Editor**.

1. Launch **Panel Builder**. The **Welcome** screen appears.

2. Click the **New** button.

3. Enter a **Panel Name**, **Width**, and **Height**.

4. Click **Add**.

FIG. 38 Beginning a New Project in Panel Builder

5. The system launches the **Project Editor** (as shown in [Figure 39](#)).




FIG. 39 Project Editor

NOTE: For step-by-step panel building instructions, refer to the *Panel Builder Tutorial* (available in the *Panel Builder Help menu*).

Once you arrive at the main **Project Editor** page, the following screen is displayed. See the sections referenced in the callouts for descriptions of each area of the **Project Editor** interface.

See the section *Top Ribbon Option Descriptions* on page 45 for descriptions of the interface's top ribbon of options and icons.

See the section *Project Pane Option Descriptions* on page 47 for descriptions of this section of the interface.



See the section *Tools Pane Option Descriptions* on page 50 for descriptions of this section of the interface.

FIG. 40 Project Editor Section References

Top Ribbon Option Descriptions

Refer to [Table 25](#) for detailed descriptions of the options available in the top ribbon of the **Project Editor** initial page. Hold the **Shift** key when selecting multiple buttons/widgets (for aligning groups of objects, etc.).

TABLE 25 Top Ribbon Option Descriptions

























Option	Description
File	Open new and existing projects, save or delete projects, and perform import/export project functions.
View	Preview the current panel in a separate browser window or open the setup script in the Panel Builder editor to view/edit.
Window	Select Tools Pane to display the left pane of the interface (which allows you to add buttons/sliders/etc. to your panel). Select Project Pane to display the right pane of the interface (which allows you to further edit the panel you are building as well as the overall project, add scripts, etc.).
Help	Select Editor to view a tutorial for Panel Builder, Modules to view a list of module scripts, Scripts to view a user guide for Panel Builder scripting, or Commands to view a list of direct control API commands.
	Create a copy of the selected button or widget. This will also clone any scripts/conditionals that are loaded onto the button.
	Use to make all buttons the same size. The first button you select (highlighted in green) will be the size that the other selected buttons (highlighted in blue) will conform to when this icon is clicked. Hold the Shift key to select multiple objects.
	Left-align the selected buttons or widgets to the main selected item. The first button you select (highlighted in green) stays in position as the other selected buttons (highlighted in blue) are aligned to it. Hold the Shift key to select multiple objects.
	Right-align the selected buttons or widgets to the main selected item. The first button you select (highlighted in green) stays in position as the other selected buttons (highlighted in blue) are aligned to it. Hold the Shift key to select multiple objects.
	Top-align the selected buttons or widgets to the main selected item. The first button you select (highlighted in green) stays in position as the other selected buttons (highlighted in blue) are aligned to it. Hold the Shift key to select multiple objects.
	Bottom-align the selected buttons or widgets to the main selected item. The first button you select (highlighted in green) stays in position as the other selected buttons (highlighted in blue) are aligned to it. Hold the Shift key to select multiple objects.
	Center-align the selected buttons or widgets horizontally. Hold the Shift key to select multiple objects.
	Center-align the selected buttons or widgets vertically. Hold the Shift key to select multiple objects.
	Center-align the selected buttons or widgets horizontally and vertically. Hold the Shift key to select multiple objects.
	Align and evenly distribute the selected buttons or widgets horizontally. Hold the Shift key to select multiple objects.
	Align and evenly distribute the selected buttons or widgets vertically. Hold the Shift key to select multiple objects.
	Align the selected buttons or widgets to the grid. Allows you to select the number of rows/columns and then aligns the selected objects to that grid. Hold the Shift key to select multiple objects.
	Open the script editor and assign/change scripts for the selected button or widget.
	Delete the selected button(s) and/or widget(s).
	Zoom in.
	Zoom out.
	Click/drag to reposition the panel on the screen.

TABLE 25 Top Ribbon Option Descriptions (Cont.)

Option	Description
	Resize and center the project to fit the current browser window.
	Undo previous action.
	Redo a previous action that was undone using the undo  function (see above).
	Delete a panel from the current project.
	Add a panel to the current project.
	Scroll through the panels of the current project.

Project Pane Option Descriptions

On the right side of the main screen, you will find options that allow you to edit the current panel you are building, your overall project, as well as view your project assets (such as available images, created scripts, and related modules). If you do not see this pane displayed on the main page of the **Project Editor**, select **Window > Project Pane**.

This section shows the screens associated with these options as well as tables that contain details regarding each screen.

Item Properties Tab

Refer to [Figure 41](#) and [Table 26](#) for detailed descriptions of the options available on the **Item Properties** tab. You must have an item (button or widget) selected before clicking this tab in order to view the options.




FIG. 41 Item Properties Tab Pane

TABLE 26 Item Properties Pane Option Descriptions

Option	Description
Basic	View/edit the width, height, and location of the selected item (i.e., the selected button or widget).
Layer	Choose what layer the selected item is on. Send the item Up or Down one layer, send to front (Top), or send to back (Bottom).
States	Edit/add different states for the selected item (and the associated scripts and appearances during each state).
Border	Set the border width/color/etc. for the selected item.
Box, Drop, and Text Shadow	Add/remove/adjust shadow settings for the selected item.
Touch Panel Key	Use to assign a touch panel key number (if applicable).
Icon	Choose an image to serve as an icon for the selected item.
Text	Edit the text to be displayed on the selected item.

Panel Tab

Refer to [Figure 42](#) and [Table 27](#) for detailed descriptions of the options available on the **Panel** tab.

The screenshot shows the 'Item Properties' dialog box with the 'Panel' tab selected. The 'Panel' tab is highlighted with a red circle. The dialog contains the following options:

- Name:** Panel-1 (with a 'Set' button)
- Width:** 1024 (with a 'Set' button)
- Height:** 768 (with a 'Set' button)
- Default Panel:** (checkbox)
- Auto-Resize Panel to Device:** (checkbox)
- Background Color:** FFFFFFFF (with a color picker icon)
- Background Image:** Choose File (with a file picker icon)

FIG. 42 Panel Tab Pane

TABLE 27 Panel Tab Option Descriptions

Option	Description
Name	View/edit the current panel's name. Click the Set button to accept changes.
Width	Set the width of the current panel (in pixels). Click the Set button to accept changes.
Height	Set the height of the current panel (in pixels). Click the Set button to accept changes.
Default Panel	Enable this checkbox to set the current panel as the device's home screen.
Auto-Resize Panel to Device	Enable this checkbox to automatically size the current panel to fit the device's screen when viewed as the active panel.
Background Color	Edit the current panel's background color.
Background Image	Select an image from your computer to be displayed as the current panel's background.

Project Tab

Refer to [Figure 43](#) and [Table 28](#) for detailed descriptions of the options available on the **Project** tab.




FIG. 43 Project Tab Pane

TABLE 28 Project Tab Option Descriptions

Option	Description
Name	View/edit the current project's name.
Setup Script	View/edit the setup script for the project.
Snap Items to Panel	Enable this checkbox to force all buttons and widgets to remain on the panel background template of the editor (i.e., the white portion of the editor screen).
Project Security Code	Enter a pass code (any combination of numbers 1 through 8) if you would like a code to be required to access that panel on the N-Touch Wall Controller. If a code has been entered, a dialog appears on the N-Touch Wall Controller's screen prompting the user to enter the key for access.
Project Tree	Lists all items in the project. Click an item in the list to select it on the actual panel.

Assets Tab

Refer to [Figure 44](#) and [Table 29](#) for detailed descriptions of the options available on the **Assets** tab.




FIG. 44 Assets Tab Pane


TABLE 29 Assets Tab Option Descriptions

Option	Description
Images	View all images in the project.
Scripts	Creates scripts that can be dragged and dropped onto multiple buttons at once.
Modules	Use to control a specific type of device with the commands specific to that item.

Tools Pane Option Descriptions

On the left side of the main screen, you will find options that allow you to access/create buttons, access widgets (such as sliders, text fields, etc.), as well as store panel templates for future use. If you do not see this pane displayed on the main page of the **Project Editor**, select **Window > Tools Pane**.


To add a button or widget to your project, simply drag and drop it onto your module display as shown in [Figure 45](#).

**FIG. 45** Adding a Button to the Display

This section shows the screens associated with these options as well as tables that contain details regarding each screen.

Buttons Tab

Refer to [Figure 46](#) and [Table 30](#) for detailed descriptions of the options available under the **Buttons** tab.

**FIG. 46** Buttons Tab Pane**TABLE 30** Buttons Tab Option Descriptions

Option	Description
Default/User Buttons	Choose Default Buttons from the drop-down menu to access all of the system buttons. Select User Buttons to access buttons created previously to use as a template. Drag and drop to add a button you created to the User Button library.
	Click the down arrow to export a selected button to your computer. Click the up arrow to browse to a (previously exported) button file and import it into the User Button library.

Widgets Tab

Refer to [Figure 47](#) and [Table 31](#) for detailed descriptions of the options available on the **Widgets** tab.




FIG. 47 Widget Tab Pane

TABLE 31 Widget Tab Option Descriptions

Option	Description
Sliders	Allows script to fill in value from 0 to 100 (or custom values between two numbers).
Text	Adds text to the panel.
Image	Adds an image to the panel. Drag and drop this icon to the panel and then double-click it to select an image file (supports .gif, .jpg, or .png file types).
Dialer widget	Adds keypad to the panel (for data entry).
NVR Control widget	Adds play, stop, pause, etc. buttons for network video recorder (NVR) control.

Templates Tab

Refer to [Figure 48](#) and [Table 32](#) for detailed descriptions of the options available on the **Templates** tab.







FIG. 48 Templates Tab Options

TABLE 32 Templates Tab Option Descriptions


Option	Description
	Click the left arrow button to add the current panel to the template page. Click the right arrow button to apply the template to the current panel.
	Deletes the currently selected template.
	Click the down arrow to export the template library to your computer. Click the up arrow to browse to a (previously exported) file and import it into the template library. When buttons are exported, they become .zip files.

Now that you have familiarized yourself with the interface options, use the tutorials provided in the **Help** menu of **Panel Builder** to further explore its capabilities.

Appendix B: Wall Builder Tutorial

N-Command's Wall Builder allows you to design walls of any size in minutes using N-Series Networked AV Encoders, Decoders, and Windowing Processors. The configuration utility is part of the N-Command Controller and provides a user-friendly interface to customize video wall layouts to suit the need of the installation. The Wall Builder utility allows the manipulation of N-Series encoded video sources to be arranged in almost any configuration on the video wall. Wall Builder is easy to use and operate, and it allows you to build a wall on-site or remotely using N-Series Windowing Processors and/or Decoders.

Video walls require a Decoder per display panel, but can be constructed with or without Windowing Processors. See [Figure 49](#) for an example of a 3x3 wall using nine Decoders.



*In this example, all Decoders are watching the same stream.

FIG. 49 Sample Wall Builder Configuration

NOTE: Some advanced configurations require Windowing Processors. Without them, video windows must be bound by the displays. When using one Windowing Processor per display, video windows can be anywhere on the full video wall pallet at pixel-by-pixel resolution. Including Windowing Processors in a video wall adds to its presentation capabilities but increases video latency by approximately 100 milliseconds.

Wall Builder Basics

Keep the following guidelines and terminology in mind while building your wall:

- Wall Builder allows you to create multiple *layouts* for the same *wall* configuration.
- Within a *layout* there are multiple *windows*.
- The *windows* can be layered to determine which one is displayed on top (if two windows overlap).

NOTE: Windows can only overlap when using Windowing Processors.

Sample Configuration Using Wall Builder

This tutorial demonstrates a 3x3 video wall configuration using nine N2000 Series Decoders (one for each display).

1. Log in to your N-Command Controller.
2. Select **Build > Wall Builder** (as shown in [Figure 50](#)).




FIG. 50 Launching Wall Builder

3. The first **Wall Builder Setup** screen appears. For this tutorial, follow the steps given in [FIG. 51 on page 53](#) to create a wall from Decoder sources.


Choose **N2K Decoders** for this example.

Name your new wall, determine the number of rows and columns, and choose the output mode.

Note: Control through any control system requires the video wall name. Control commands are case/space sensitive, so simple names with no spaces work best.

Enter the selected Decoder IP addresses you would like to use.

Click **Save**.



The 'Wall Settings' window contains the following elements:

- Radio Buttons:** N2k Decoders (selected), N1k Decoders, Windowing Processors, 4K Decoders.
- Wall Name:** A text input field with the placeholder 'Wall Name'.
- Size:** Input fields for 'Size' (value 3), 'Rows' (value 3), and 'Columns'.
- Output Mode:** Radio buttons for 1080p (selected), 720p, and 4K.
- Coordinates:** A note stating 'Coordinates are from top left to bottom right.'
- Unit IP List:** A scrollable list of input fields for unit IP addresses, labeled 'Unit 0,0', 'Unit 0,1', 'Unit 0,2', 'Unit 1,0', and 'Unit 1,1'. Each field has a clear 'X' button.
- Buttons:** 'Save' and 'Close' buttons at the bottom right.

FIG. 51 Configuring the Wall Builder Setup Page

- The screen shown in [Figure 52](#) appears. Refer to the guidelines and option descriptions given in [Figure 52](#), [Figure 53](#), and [Table 33](#) as you create your design.

Refer to [Figure 53](#) for descriptions of this portion of the interface.

If an area is not covered by a window (in a Decoder-only setup), Local Play displays. However, when using Windowing Processors, a blank area will display the Windowing Processor's background graphic (which can be customized to suit your application).

Refer to [Figure 53](#) for descriptions of this portion of the interface.

Click the + button to add windows to your wall.

The new window appears at the top-left. Drag/drop and resize as desired. Hold the **<Shift>** key to maintain aspect ratio.




FIG. 52 Arranging the Wall




FIG. 53 Wall Arrangement Page: Top Menu Bar Icons

TABLE 33 Wall Arrangement Options

Option	Description
File drop-down menu	Choose to create a new wall, open an existing project, save, delete, import, etc.
Source drop-down menu	Change the source for the selected window. The current source name is displayed at the top of the window. Note: All windows must have a default source that will be recalled when a preset is recalled.
X, Y fields	Enter the x and y coordinates of where you would like the window's upper left-hand corner to be re-positioned (or you can use mouse to re-size).
W, H fields	Enter width and height values (in pixels) to re-size the selected window (or use mouse to re-size).
16:9 checkbox	Enable to lock all the windows to a 16:9 aspect ratio.
Layer drop-down menu	Choose a layer number for the selected window. The window with the highest layer number is displayed in the front and the lowest is displayed in the back. Note: Layer numbers are also used for video wall switching commands. All windows must have a unique layer number to avoid accidentally affecting multiple windows with a command.
Add Window button	Click to add a new window to the current layout.
Remove Window button	Click to remove the selected window from the current layout.
Show Script button	Displays the generated script from the layout that are sent to each Decoder for wall setup. These can be copy/pasted into Script Builder .
Take button	Click to view the current layout on your displays.
Auto checkbox	Click to automatically send a Take command whenever the layout changes.
Editing field	Selects/displays the wall currently being edited. It is important to note that you can create multiple layouts for a given wall. As you create and save the different layouts, they will appear as selections at the bottom of the screen.

Appendix C: Minimum Network Requirements

The following list specifies the minimum network requirements that must be considered when deploying your equipment. These requirements cover the necessary protocols and features needed to drive N-Series streams.

NOTE: *Specific configuration recommendations are based off of the Cisco Catalyst series. These recommendations could vary from manufacturer to manufacturer.*

1. **Managed Network Switch**
2. **Gigabit Ethernet (N1000/2000 Based Systems)**
3. **Internet Group Management Protocol (IGMP) Version 2**
 - IGMP Snooping
 - Snooping must be enabled on all switches that are communicating with the querier.
 - IGMP Snooping Querying
 - Network must include at least one IGMP Querier to maintain stream connections.
 - It is recommended to have all capable switches with the querier enabled and allow IGMP auto-elect to determine the Designated Querier (DQ). DQ is determined by the lowest IP addressed switch, but can be manually assigned. However, this would need to be manually configured on all switches to bypass the auto-elect.
 - Query interval – 30 seconds. This is the interval between sending IGMP general queries.
 - Query Response Interval – 10 seconds. This is the maximum time the system waits for a response to general queries.
 - Last Member Query Interval – 100 milliseconds. This is the interval to wait for a response to a group specific or group-and-source-specific query message.
 - Immediate Leave (required for N1000, N2x51 4K, N2300 4K, N2400, and N2x35 [Extreme Quality] Low Latency Models)
 - Used to immediately break up multi-cast groups when a leave message is received.
 - Immediate Leave will break any daisy chaining of multiple units together with a single home run and as such you will not be able to have both Immediate Leave and daisy chaining in the same VLAN.
 - Some manufacturers do not have Immediate Leave as an option and use Fast Leave instead. Fast Leave does not guarantee an immediate leave from the multi-cast group and can affect switching speeds and performance.
 - Optional Protocols
 - IGMP Robustness – Default 2
 - a. Robustness can be adjusted generally from 2-10. The higher the value, the more leave latency is added.
 - b. This protocol is effectively inactive when Immediate Leave is enabled.
 - Warnings/Notices
 - There is a known behavior within IGMP V2 that Encoder streams, whether requested across an uplink or not, will be requested by the DQ and will be present on the uplinks of all switches between the stream source switch and the DQ.
 - Essentially this means that even though you may not be routing a stream to another switch, the DQ's request will still put the stream on the uplink. Therefore, ensure that you have accounted for all streams forwarding to the DQ.
 - A good rule of thumb, when planning for bandwidth considerations on uplinks, is to not exceed 80% of the uplink's total bandwidth capacity to give plenty of overhead for spikes and additional traffic.
 - Multicast routing capabilities on each switch (configured for PIM-SM and with an established rendezvous point) can be designed to limit or mitigate this behavior.
 - When a multicast host leaves a group, it sends an IGMP leave message. When the leave message is received by the switch, it checks to see if this host is the last to leave the group by sending out an IGMP group-specific or group-and-source specific query message, and starting a timer. If no reports are received before the timer expires, the group record is deleted and a report is sent to the upstream multicast router/querier switch. Lower interval times will increase bandwidth utilization slightly as querying will happen more often.
4. **Protocol Independent Multicast (PIM)**
 - Used to route multicast between VLANs
 - PIM Sparse Mode (PIM-SM)
 - Recommended for use with N-Series multicast products.
 - PIM-SM uses a pull model to deliver multicast traffic. Only network segments with active receivers that have explicitly requested the data will receive the traffic.
 - Requires configuration of a Rendezvous Point (RP).
 - Must be configured by administrator.
 - Similar to the DQ in IGMP.
 - All multicast sources must register with the RP to be able to be routed throughout the network.
 - Other PIM modes – not recommended for N-Series
 - Dense Mode (PIM-DM)
 - Bidirectional (bidir-PIM)
5. **Jumbo Frames Enabled (For N2300 Series)**
 - The N2300 Series Encoders and Decoders produce a frame payload larger than 1500 bytes. This requires the switch to have the capacity of handling jumbo frames enabled.
6. **Quality of Service (QoS): Managing the delay, delay variation (jitter), bandwidth, and packet loss parameters on a network becomes the secret to a successful end-to-end business solution.**
 - Not required for use with N-Series devices
 - Policing

- ❑ A policer typically drops traffic.
- ❑ Differentiated Services Code Point (DSCP) values can be configured in N-Series devices if QOS is required on the network.
- Shaping
 - ❑ A shaper typically delays excess traffic using a buffer, or queueing mechanism, to hold packets and shape the flow when the data rate of the source is higher than expected.
 - ❑ Cannot be used with N2300 series.
- 7. **TCN Flood Off**
 - TCN (Topology Change Notification) flooding will cause unnecessary backplane and bandwidth usage when adding or removing a device on the network, which can cause stream interruptions as the flooding sweeps through the network.
 - ❑ Note that this command has to be assigned individually per port that is assigned to that VLAN. However it is not necessary with ports on the same switch that will not be set up on the same VLAN as the N-Series devices.
 - Command Example: NO IP IGMP SNOOPING TCN FLOOD

Should you encounter any problems not covered by these guidelines, please contact technical support via email (svsisupport@harman.com) or call 256.461.7143 x9900.

Appendix D: N-Command Failover Configuration

Introduction

You can configure N-Command for failover support by establishing a master/slave relationship between two N-Command devices. Once properly configured, the system behaves as follows:

- If a master unit fails, the slave unit initiates SVSI system services and assumes the eth0/eth1 IP addresses of the master unit.
- Any third-party controller communicating with the N-Command detects the failover only as a momentary disruption because the slave assumes the master's old IP addresses.
- When the master is back on-line, it overrides the slave and resumes control.
- Once the master resumes control, the slave releases the assumed IP addresses and returns to monitoring the master's status.

NOTE: The failover feature is supported by the N8002 and N8012 N-Command devices (not by the N8001).

Needed equipment

Required equipment for an N-Command master/slave system includes:

- Two N8002/N8012 N-Command units
- Network cables, power source, computer with web browser, etc.

Connection Diagram

All communication between the two N-Command units is performed through their eth0 and eth1 connections and binded to the third IP address. Each N-Command monitors each other's health. See [Figure 54](#).




FIG. 54 Connection Diagram

This means during normal operation the master eth0 and eth1 card will have at least two IP address: one for normal Encoder/Decoder management and another for master/slave communication. When the slave takes control, it assumes all the IP addresses of the master except for the third IP address of each card.

General Functionality

Every minute, the master communicates with the slave, and the slave communicates with the master. The communication between the two determines if a failover scenario has occurred or if it is time to sync the databases. All communication is performed through https master/slave web services. See the [Failover Scenarios section on page 58](#) for more details on failover conditions.

- During *master > slave* communication, if the master detects the slave has tried to take control, and the master's own databases and services are good, then the master will override the slave, and the slave will shut down most system services and begin syncing with the master. The most common reason a slave may have taken control with a good master is if the slave or master (or both) were disconnected from the network.
- During *slave > master* communication, the slave is asking the master for its system health status. Three bad health reports (including a non-communicative master) will trigger a failover. Every ten minutes, if the master says its database is good, the slave asks for a copy of the database. The master generates, compresses, and

encrypts its database, and then the slave transfers, decrypts, and imports it in to itself. The transferred database contains essentially all static settings (scripts, tasks, units, users, panels, system settings, etc.).

NOTE: *The LocalPlay audio/image library is not part of the transferred database.*

Failover Scenarios

The following scenarios constitute a failover, causing the slave to take control.

- **Loss of communication** with the master for a period of three minutes (on both network cards).
 - Every minute, the slave queries the master. If it gets no response three times in a row, the slave assumes the master is offline.
 - Both network cards need to be down for communication to be lost. If eth1 is down and eth0 is working, the status is considered good.
- **Database errors** for a period of three minutes.
 - Every minute, the slave asks the master the status of its database. If the master reports a database problem three times in a row, the slave takes over.
- **System services down** for a period of three minutes.
 - Every minute, the slave asks the master the status of its system services. If the master reports services are down three times in a row, the slave takes over and the master shuts itself down. The master determines the state of system services by monitoring a list of running processes.
- **Any combination of the above** has occurred for a period of three minutes.
 - For example, if the master is reported offline, followed by a report of services down, followed by database errors, then the slave will take over (due to too many errors in a row). The error count restarts only if the master reports a full level of health.

Override Mechanisms

To override a unit, one unit (usually the master) sends the other unit a command to shut down. This causes the receiving unit to turn off SVSI system services, release its old IP addresses, and then begin monitoring.

Overriding mechanisms include the following:

- **Slave overriding master.** Slave only overrides master during the failover scenarios.
- **Master overriding slave.** If at any time the master detects the slave has taken control, and the master has determined its own health is good, it will send the override command.
- **User overriding.** During initial setup, when an administrator is determining the master and slave, the master N-Command will send an override command to the slave N-Command.

Setup

1. Decide which unit will be the master and which unit will be the slave. Units are shipped from the factory with this setting unassigned.
2. Configure the **Static 3rd** IP addresses for each unit and eth card. It is highly recommended that the master and slave 3rd IPs are in their own subnet. They will not need to communicate with any other device except each other. See [Figure 55](#).

The screenshot shows a configuration window with a dark background. It has two main sections. The first section is for 'Static 2nd address', which is currently 'disabled' and has a 'Disable' button with a dropdown arrow. Below this are empty input fields for 'IP address' and 'Netmask'. The second section is for 'Static 3rd (master/slave) enabled', which is currently 'enabled' and has an 'Enable' button with a dropdown arrow. Below this are input fields for 'IP address' (containing '172.10.21.202') and 'Netmask' (containing '255.255.255.252').

Static 2nd address	disabled	Disable ▾
IP address		
Netmask		
Static 3rd (master/slave) enabled		Enable ▾
IP address	172.10.21.201	172.10.21.202
Netmask	255.255.255.252	255.255.255.252

FIG. 55 Configure IP Addresses

A 2nd address is not required, so it is left blank. The 3rd IP address has a subnet just big enough for the master, slave, and a few spare computers for troubleshooting.

3. Repeat the 3rd IP address setup on the slave unit. Choose IP addresses for each network card within the subnet of the master. You may use the **Ping** tool on the IP settings page to check communication.
4. If you do not have strict IP requirements, an example master/slave IP configuration could be:

Master

- Eth0: 172.10.21.201 / 255.255.255.252
- Eth1: 172.20.21.201 / 255.255.255.252

Slave

- Eth0: 172.10.21.202 / 255.255.255.252
- Eth1: 172.20.21.202 / 255.255.255.252

5. Navigate to **Admin > Master / Slave** on the master unit. Now that the 3rd IP addresses are configured, the menu shows other N-Commands it has found on the network and offers to configure them to be the slave. See [Figure 56](#).




FIG. 56 Choose Slave

6. The slave must have its 3rd IP addresses configured. If the unit is not configured correctly, N-Command will offer the address so you may configure it.




FIG. 57 Configure Slave Address

7. Once all addresses are configured, click the **Assign Master and Slave** button to set up master/slave. You may also use the **Ping** tool to check connections. N-Command internally tests configurations before accepting the unit as slave. See [Figure 58](#).





FIG. 58 Assign Master and Slave

[Figure 59](#) shows some possible status messages once master/slave configuration is successful.

The screen below displays when logged into the slave's 3rd IP address and the slave has not taken over.



The screen below displays when logged into the slave's 3rd IP address (or the master's IP address) after the slave has taken over.



FIG. 59 Status Messages

Stopping Master/Slave

At any time, the master/slave relationship can be severed by navigating (on each unit) to **Admin > Configure master/slave** and setting the unit to **Unassigned**. If system services have stopped, they will be started.

NOTE: *If the databases have been synced, this could cause duplicate IP problems. It is best to isolate the slave unit when un-pairing.*

Important Notes

- During failover/override transitions, the N-Command units are reconfiguring their network cards to new IP addresses. Units that are connected will see the connection broken and will need to reestablish connection (very common occurrence for network devices).
- A master will not override another master. If a system is misconfigured and has two masters, both units will start as normal and refuse to override each other.
- If a system is misconfigured to have two slaves, whichever unit boots first will take control.
- A slave will not attempt to import if the master says its data is not good.
- There are no configuration options on the slave. The master dictates everything.
- Data only flows from the master to the slave. The master never imports from the slave.
- Once configured for master/slave, the slave's web page is accessible only from the 3rd IP addresses (until a failover or it is **Unassigned**).



© 2018 Harman. All rights reserved. AMX, AV FOR AN IT WORLD, and HARMAN, and their respective logos are registered trademarks of HARMAN. Oracle, Java and any other company or brand name referenced may be trademarks/registered trademarks of their respective companies. AMX does not assume responsibility for errors or omissions. AMX also reserves the right to alter specifications without prior notice at any time. The AMX Warranty and Return Policy and related documents can be viewed/downloaded at www.amx.com.
3000 RESEARCH DRIVE, RICHARDSON, TX 75082 AMX.com | 800.222.0193 | 469.624.8000 | +1.469.624.7400 | fax 469.624.7153
AMX (UK) LTD, AMX by HARMAN - Unit C, Auster Road, Clifton Moor, York, YO30 4GD United Kingdom • +44 1904-343-100 • www.amx.com/eu/

Last Revised:
4/2018
850DOCN8000MNREV1.3