


PRX800

S E R I E S




QUICKSTART GUIDE


UNBOX IT



1




2




3

1. Open the top of the box.
2. Lay box on its side.
3. Turn box upside down, then lift box up to reveal speaker.


OPTIONAL SETUPS




1




2




3



4



5



6

1. Floor Standing
2. Monitor
3. Pole Mounted

4. Sub Mounted
5. Suspended
6. Subs with 3-way played

