

P3 System Controllers™ Shortcuts Overview

As of P3 System Controller software release 4.3.0.

Ctrl+Z	Undo
Ctrl+Y	Redo
Scroll wheel	Scroll workspace up/down
Alt+Scroll wheel	Scroll workspace left/right
D	Scroll-drag toggle
Space	Scroll-drag while held
Ctrl+Scroll wheel	Zoom in/out
Ctrl++	Zoom in
Ctrl+0	Reset zoom (zoom to 100%)
Ctrl+-	Zoom out
Backspace+Enter	Lock P3 System Controller
Esc	Stop adding fixtures (when in multi mode)
H	Highlight selected fixture(s)
Ctrl+A	Select all
Ctrl+Select	Select multiple fixtures (on workspace or devices list)
Shift+Select	Select range of fixtures (in devices list)
Delete	Delete selected
Ctrl+C	Copy
Ctrl+V	Paste
Ctrl+G	Group
Ctrl+U	Ungroup
Up/Down/Left/Right	Move selected fixtures by pixel pitch
Alt+Up/Down/Left/Right	Move selected fixtures by grid spacing
R	Rotate selected fixture(s) 90 degrees around its center
Shift+R	Rotate selected fixture(s) 45 degrees around its center
Tab	Jump to next pixel within flexible fixture (VC-Dots)
Shift+Tab	Jump to previous pixel within flexible fixture (VC-Dots)
Ctrl+Shift+A	Toggle fixture/device selection
F1-F12	Recall preset 1-12 (if preset shortcuts enabled in preferences)
Shift+F1-F12	Recall preset 13-24 (if preset shortcuts enabled in preferences)
Ctrl+F1-F12	Recall preset 25-36 (if preset shortcuts enabled in preferences)
Alt+F1-F12	Recall preset 37-48 (if preset shortcuts enabled in preferences)