


## **RUSH MH3**

## Please make surer that there is no risk of electrical hazards when adjusting the lamp.

First power on the fixture, and check the light beam of the lamp, whether the spot is in the centre of the beam. If yes, then you do not need to do this adjustment, if no then follow the instruction as below

## Adjustment instruction for lamp movement of left to right

- 1. Open the head cover of the fixture
- 2. Turn the post as below picture to move the lamp to left or right, until the spot is in the center of the beam in horizontally.





## Adjustment instruction for lamp movement of up to down

- 1. Connect the fixture with one control desk
- 2. Enter the offset menu as below picture; adjust the data of gobo by up/down button, until the spot is in the center of the beam in vertically.



3. Load the covers of the fixture.

