

Display Messages EP500

Displayed message	Signal source	Solution
Err Gobo Wheel	Gobo wheel rotation hall sensor	Check hall sensor, gobo wheel motor, connection, missing magnet.
Err Gobo ind/rot	Gobo Index rotation hall sensor	Check hall sensor, gobo index rotation motor, connection, missing magnet
Err Prism Wheel	Prism wheel Hall sensor.	Check hall sensor, prism wheel motor, connection, missing magnet
Err Prism ind/rot	Prism Rotation Hall Sensor	Check hall sensor, prism wheel motor, connection, missing magnet
FAN error	FAN RPM	Check fan and connections
Should display: Err Color wheel	Color wheel Hall sensor	Check hall sensor, motor, connection, missing magnet
Should display: Err Focus	Focus hall sensor	Check hall sensor, motor, connection, missing magnet
Should display: Err Prism/Frost	Prism and frost wheel hall sensor	Check hall sensor, motor, connection, missing magnet
Should display: Err Prism rot	Prism rotation Hall sensor	Check hall sensor, motor, connection, missing magnet
Should display: Err Animation	Animation Hall sensor	Check hall sensor, motor, connection, missing magnet
Should display: Err Focus	Focus lens Hall sensor	Check hall sensor, motor, connection, missing magnet