

Release Notes

Version 1.4.1

- The 'Loads, Signal Generator' tab can be enabled or disabled in the Q-SYS Properties Panel
- The Amplifier Presets can be enabled or disabled in the Q-SYS Properties Panel
- The measured loads values are now displayed to one decimal point

Version 1.3.2

- The Polling Query rate, minimum and default changed to 150ms
- The Faster Meters controls have been moved to the Properties Panel

Version 1.2.5

- The Input Delay field was added for each amplifier input
- HiQnet addresses will now automatically populate if a compatible device is discovered at the specified IP address
- Reporting details have been improved for amplifiers that go offline or have mismatched models between the discovered device and the device selected in the plugin.

Version 1.0.1

- Dante and BLU Link faults can now be reported in Event Logging as Input Faults

Version 1.0.0

- First Public Release