

dbx: ZonePRO 1260-1261- 1260m-1261m

This module controls a dbx ZonePRO 1260, 1261, 1260m, or 1261m over RS-232



GENERAL INFORMATION

SIMPLWINDOWS NAME:	dbxZonePRO1260_61_60m_61m_Node
CATEGORY:	Device Interface
VERSION:	V3.0
SUMMARY:	This module controls a dbx ZonePRO 1260, 1261, 1260m, or 1261m over RS-232
GENERAL NOTES:	<p>RS-232 CONTROL ONLY. USE "dbxZonePRO1260_61_60m_61m_IP_NODE.umc" MODULE FOR COMMUNICATION OVER TCP-IP</p> <p>This module is meant for a single dbx ZonePRO 1260/1261 or 1260m/1261m.</p> <p>This module MUST be used to communicate with any ZonePRO unit. This module will handle all connection "keep-alive" communication, as well as distributing all incoming serial traffic to the proper module(s).</p> <p>This module is designed to be used in conjunction with the "dbxZonePRO1260_61_60m_61m_Router.umc" module and "dbxZonePRO1260_61_60m_61m_Mixer.umc" module. Because the user can choose whether to have a mixer or router for each of the 6 output zones, the Crestron programmer must use the proper module to match the ZonePRO's configuration. Connect the 'tx_ModuleX' and 'rx_ModuleX' signals from the Node module to the corresponding Mixer or Router module in each zone. See example program.</p> <p>This module controls a dbx ZonePRO 1260/1261 or 1260m/1261m. The ZonePRO 1260/1261/1260m/1261m has 6 outputs and 12 inputs. The Node module controls all 12 input volumes, handles the incoming/outgoing serial traffic, and handles the serial traffic for the 6 mixer/router modules. For each output you can use either a Router module or a Mixer module.</p> <p>The Router module controls the zones input source, adjusts the output zones master volume, and toggle the mute status. The Mixer module can control all 12 mixer input volumes, the mixer master output volume, and master mixer mute.</p> <p>This module handles live - feedback. So whenever something is changed manually on the ZonePRO, the module will receive an update and adjusts its outputs. In order to enable live-feedback, you have to pulse the Enable_Feedback input every time the ZonePRO is rebooted.</p> <p>NOTE: When statuses are changed using the module, the feedback of the module is simulated. When statuses are changed using the ZonePRO, the feedback is real.</p> <p>Usually the address parameters will be:</p> <p>ObID_Module1: \x01\x05\x00\x1E for 1260/1261 \x01\x05\x00\x22 for 1260m/1261m</p> <p>ObID_Module2: \x01\x05\x01\x1F for 1260/1261 \x01\x05\x01\x23 for 1260m/1261m</p> <p>ObID_Module3: \x01\x05\x02\x20 for 1260/1261 \x01\x05\x02\x24 for 1260m/1261m</p>



```

ObID_Module4:
  \x01\x05\x03\x21 for 1260/1261
  \x01\x05\x03\x25 for 1260m/1261m
ObID_Module5:
  \x01\x05\x04\x22 for 1260/1261
  \x01\x05\x04\x26 for 1260m/1261m
ObID_Module6:
  \x01\x05\x05\x23 for 1260/1261
  \x01\x05\x05\x23 for 1260m/1261m
The rest are the same for both the 1260/1261 and 1260m/1261m
ObID_inputVol1: \x01\x01\x00\x00
ObID_inputVol2: \x01\x01\x01\x01
ObID_inputVol3: \x01\x01\x02\x02
ObID_inputVol4: \x01\x01\x03\x03
ObID_inputVol5: \x01\x01\x04\x04
ObID_inputVol6: \x01\x01\x05\x05
ObID_inputVol7: \x01\x01\x06\x06
ObID_inputVol8: \x01\x01\x07\x07
ObID_inputVol9: \x01\x01\x08\x08
ObID_inputVol10: \x01\x01\x09\x09
ObID_inputVol11: \x01\x01\x0A\x0A
  
```

However, since these addresses will differ depending on the unit's configuration, please ask the dbx installer for the correct information. See <http://www.dbxpro.com/Download/index.htm> for help documents showing how to get these objectID's, and for detailed protocol specifications

*"If the default configuration is not loaded into the ZonePRO, then the user must manually enter the Object ID addresses for each device. To get the object ID address, start the PC software for ZonePRO. The easiest way to get the Object ID in **decimal** format is to click on the device in the ZonePRO program screen and press <Ctrl>+<Shift>+<O> and a dialog box will appear with the correct address. Note that bit 0 is presented at the top and bit 3 at the bottom of the dialog box. Enter this Object ID address in the Crestron module parameter field in **HEX** as b3,b2,b1,b0.*

Another easy way to get the Object ID address in hex is to click on the device symbol in the ZonePRO Designer window and press Ctrl + Shift + T to open the Network Trace Window. Click on the ZonePRO object you want the address for in the software. Change the value of the mute button, volume control, or any other control you are interested in and look for the first row of "MULTSVSET" in the Network Trace Window. Click on this line and look in the window "Frame Data". The object ID will always be the 8th, 9th, 10th, and 11th byte. Enter this 4 byte value into the address parameter on the front of the Crestron module. Repeat this for every address parameter on the front of the module." - DBX

CRESTRON HARDWARE REQUIRED:

2-series or X-series processor

SETUP OF CRESTRON HARDWARE:

Pro2 with TPS-6000
Com Port Settings: 57600, 8, 1, N

VENDOR FIRMWARE:


V2a-1.110

VENDOR SETUP:

ZonePRO I260/1260m



CABLE DIAGRAM:



CONTROL:

Enable_Feedback	D	Pulse to enable live feedback. Pulse once every time the processor or the ZonePRO restarts
Disco	D	Pulse to send a disco message. The ZonePRO will then report back with it's Node Address. Before this, all commands will be send to default node address \x00\x20 (32 decimal)
Input_VolumeChX	A	Sets the volume for input channel X 0d (0%) = -inf (less then -60 dB) 65535d (100%) = 20.0 dB
tx_moduleX	S	Connect to zone X module's 'module_tx'. In other words, this can come from either a 'dbxZonePRO1260_61_60m_61m_Router.umc' module or a 'dbxZonePRO1260_61_60m_61m_Mixer.umc' module depending on the configuration loaded inside the ZonePRO.
rx_CommPort	S	To be connected to rx of the com port

FEEDBACK:



Input_VolChX_fb	A	Current volume for input channel X
rx_moduleX	S	Connect to zone X module's 'module_rx'. In other words, this can come from either a 'dbxZonePRO1260_61_60m_61m_Router.umc' module or a 'dbxZonePRO1260_61_60m_61m_Mixer.umc' module depending on the configuration loaded inside the ZonePRO.
tx_CommPort	S	To be connected to tx of the com port

PARAMETERS:

		<p>The address to which commands have to be send to reach the appropriate control.</p> <p>Usually those will be:</p> <table><tr><td></td><td>1260/1261</td><td> 1260m/1261m</td></tr><tr><td>obID_Module1:</td><td>\x01\x05\x00\x1E</td><td> \x01\x05\x00\x22</td></tr><tr><td>obID_Module2:</td><td>\x01\x05\x01\x1F</td><td> \x01\x05\x01\x23</td></tr><tr><td>obID_Module3:</td><td>\x01\x05\x02\x20</td><td> \x01\x05\x02\x24</td></tr><tr><td>obID_Module4:</td><td>\x01\x05\x03\x21</td><td> \x01\x05\x03\x25</td></tr><tr><td>obID_Module5:</td><td>\x01\x05\x04\x22</td><td> \x01\x05\x04\x26</td></tr><tr><td>obID_Module6:</td><td>\x01\x05\x05\x23</td><td> \x01\x05\x05\x27</td></tr><tr><td>obID_inputVol1:</td><td>\x01\x01\x00\x00</td><td></td></tr><tr><td>obID_inputVol2:</td><td>\x01\x01\x01\x01</td><td></td></tr><tr><td>obID_inputVol3:</td><td>\x01\x01\x02\x02</td><td></td></tr><tr><td>obID_inputVol4:</td><td>\x01\x01\x03\x03</td><td></td></tr><tr><td>obID_inputVol5:</td><td>\x01\x01\x04\x04</td><td></td></tr><tr><td>obID_inputVol6:</td><td>\x01\x01\x05\x05</td><td></td></tr><tr><td>obID_inputVol7:</td><td>\x01\x01\x06\x06</td><td></td></tr><tr><td>obID_inputVol8:</td><td>\x01\x01\x07\x07</td><td></td></tr><tr><td>obID_inputVol9:</td><td>\x01\x01\x08\x08</td><td></td></tr><tr><td>obID_inputVol10:</td><td>\x01\x01\x09\x09</td><td></td></tr><tr><td>obID_inputVol11:</td><td>\x01\x01\x0A\x0A</td><td></td></tr></table>		1260/1261	1260m/1261m	obID_Module1:	\x01\x05\x00\x1E	\x01\x05\x00\x22	obID_Module2:	\x01\x05\x01\x1F	\x01\x05\x01\x23	obID_Module3:	\x01\x05\x02\x20	\x01\x05\x02\x24	obID_Module4:	\x01\x05\x03\x21	\x01\x05\x03\x25	obID_Module5:	\x01\x05\x04\x22	\x01\x05\x04\x26	obID_Module6:	\x01\x05\x05\x23	\x01\x05\x05\x27	obID_inputVol1:	\x01\x01\x00\x00		obID_inputVol2:	\x01\x01\x01\x01		obID_inputVol3:	\x01\x01\x02\x02		obID_inputVol4:	\x01\x01\x03\x03		obID_inputVol5:	\x01\x01\x04\x04		obID_inputVol6:	\x01\x01\x05\x05		obID_inputVol7:	\x01\x01\x06\x06		obID_inputVol8:	\x01\x01\x07\x07		obID_inputVol9:	\x01\x01\x08\x08		obID_inputVol10:	\x01\x01\x09\x09		obID_inputVol11:	\x01\x01\x0A\x0A	
	1260/1261	1260m/1261m																																																						
obID_Module1:	\x01\x05\x00\x1E	\x01\x05\x00\x22																																																						
obID_Module2:	\x01\x05\x01\x1F	\x01\x05\x01\x23																																																						
obID_Module3:	\x01\x05\x02\x20	\x01\x05\x02\x24																																																						
obID_Module4:	\x01\x05\x03\x21	\x01\x05\x03\x25																																																						
obID_Module5:	\x01\x05\x04\x22	\x01\x05\x04\x26																																																						
obID_Module6:	\x01\x05\x05\x23	\x01\x05\x05\x27																																																						
obID_inputVol1:	\x01\x01\x00\x00																																																							
obID_inputVol2:	\x01\x01\x01\x01																																																							
obID_inputVol3:	\x01\x01\x02\x02																																																							
obID_inputVol4:	\x01\x01\x03\x03																																																							
obID_inputVol5:	\x01\x01\x04\x04																																																							
obID_inputVol6:	\x01\x01\x05\x05																																																							
obID_inputVol7:	\x01\x01\x06\x06																																																							
obID_inputVol8:	\x01\x01\x07\x07																																																							
obID_inputVol9:	\x01\x01\x08\x08																																																							
obID_inputVol10:	\x01\x01\x09\x09																																																							
obID_inputVol11:	\x01\x01\x0A\x0A																																																							
ObID_X	S																																																							
		<p>However, since these addresses will differ depending on the unit's configuration, please ask the dbx installer for the correct information. See http://www.dbxpro.com/Download/index.htm for help documents showing how to get these objectID's, and for detailed protocol specifications</p>																																																						

TESTING:

OPS USED FOR TESTING:	V4.001.1012
COMPILER USED FOR TESTING:	V2.12
SAMPLE PROGRAM:	dbxZonePRO1260_61_DemoProgram.smw and dbxZonePRO1260m_61m_DemoProgram.smw
REVISION HISTORY:	V. 1.0 – Creation V. 2.0 – Dbx manufacturer update V. 3.0 – Dbx manufacturer Added Support for the 1260m and 1261m