

AMX SVSI N2600WP Decoder Installation and Usage Guide



Version: 1.0.1
Date: Saturday, May 03, 2025
Authors: Richard Mullins



Contents

Overview.....	4
Product Features.....	5
AMX SVSI N2600 Wall Plate Decoder Module.....	6
Digital Inputs.....	6
Connect.....	6
Play_Live.....	6
Play_Local.....	6
Play_Off.....	6
Mute_On.....	6
Mute_Off.....	6
HDMI_On.....	6
HDMI_Off.....	6
KVM_Enable.....	7
KVM_Disable.....	7
USB_Enable.....	7
USB_Disable.....	7
Receive_H26X.....	7
Receive_MWC.....	7
Reboot.....	7
Analog Inputs.....	7
Set_Stream.....	7
Set_Audio.....	7
Playlist.....	7
LineOut_Left.....	8
LineOut_Right.....	8
String Inputs.....	8
Send_Serial_Preset.....	8
Send_IR_Preset.....	8
Send_IR_Hex.....	8
KVM_IP_Address.....	8
RTP_Stream.....	8

Custom Command.....	8
Dynamic IP Address.....	9
Digital Outputs.....	9
Connected.....	9
Play_Live_FB.....	9
Play_Local_FB.....	9
Mute_FB.....	9
HDMI_FB.....	9
HDMI_Connection_FB.....	9
KVM_Enable_FB.....	9
USB_Enable_FB.....	9
Analog Outputs.....	9
Output_Stream_FB.....	9
Audio_Stream_FB.....	10
Playlist_FB.....	10
LineOut_Left_FB.....	10
LineOut_Right_FB.....	10
String Outputs.....	10
Model.....	10
Device_Name.....	10
MAC_Addr.....	10
Web_Version.....	10
Firmware.....	10
Input_Resolution.....	10

Overview

As the industry pioneer in video over IP, AMX has been delivering AVoIP solutions for well over a decade and can be found in many world-class installations. They offer a wide range of solutions for delivering up to 4K60 4:4:4 video, audio, USB, and control over standard gigabit networks. AMX AVoIP solutions are designed to support the latest enterprise network security features and to be configured and managed simply. AMX SVSI AVoIP solutions deliver secure, quality video wherever you need it.



Product Features

- Support for the N2600S range of encoders and decoders
- Support for the N2600 Wall Plate range of encoders and decoders
- Support for the N2400 range of encoders and decoders
- Support for the N4000 Audio Transceivers

AMX SVSI N2600 Wall Plate Decoder Module

Digital Inputs

Connect

The Connect command is used to initialize and keep the module running. It is level triggered and needs to be held high for the module to function. Sending this signal high will begin and maintain a connection to the device. Sending this signal low will disable the module.

Play_Live

The Play_Live command allows you to switch the stream to using the live connection. This signal is level based and triggered with the rising edge.

Play_Local

The Play_Local command allows you to switch to a local connection and playlist. This signal is level based and triggered with the rising edge.

Play_Off

The Play_Off command allows you to disable both the live stream and the local stream. This signal is level based and triggered with the rising edge.

Mute_On

The Mute_On command allows you to turn the audio mute on. This signal is level based and triggered with the rising edge.

Mute_Off

The Mute_Off command allows you to turn the audio mute function off. This signal is level based and triggered with the rising edge.

HDMI_On

The HDMI_On command allows you to enable the HDMI connection. This signal is level based and triggered with the rising edge.

HDMI_Off

The HDMI_Off command allows you to disable the HDMI connection. This signal is level based and triggered with the rising edge.

KVM_Enable

The KVM_Enable command allows you to enable the KVM function. This signal is level based and triggered with the rising edge.

KVM_Disable

The KVM_Disable command allows you to disable the KVM function. This signal is level based and triggered with the rising edge.

USB_Enable

The USB_Enable command allows you to enable the USB connection. This signal is level based and triggered with the rising edge.

USB_Disable

The USB_Disable command allows you to disable the USB connection. This signal is level based and triggered with the rising edge.

Receive_H26X

Changes the mode for the decoder from Motion Wavelet Compression to H.26X mode.

Receive_MWC

Changes the mode for the decoder from H.26X mode to Motion Wavelet Compression

Reboot

The Reboot command allows you to reboot the unit. This signal is level based and triggered with the rising edge.

Analog Inputs

Set_Stream

The Set_Stream command allows you to set the current stream you wish to connect to. The stream number can be found by using the steam feedback provided by the encoder modules.

Set_Audio

The Set_Audio command allows you to set the current audio stream you wish to connect to. The stream number can be found by using the steam feedback provided by the encoder modules.

Playlist

The Playlist signal is used to set a playlist. Valid range is 0 and 7.

LineOut_Left

The LineOut_Left allows you to set a value for the left channel Line Out level.

LineOut_Right

The LineOut_Right signal allows you to set a value for the right channel Line Out level.

String Inputs

Send_Serial_Preset

The Send_Serial_Preset command allows you to send a pre-configured serial string. The value used should match the preset you have configured.

Send_IR_Preset

The Send_IR_Preset command allows you to send a pre-configured IR preset. The value used should match the preset you have configured.

Send IR Hex

It is possible to send a pronto formatted hex code to the device, but due to the string length limitation in SIMPL it needs to be formatted correctly. The codes needs to have any spaces removed and must finish with a \n character.

If the total length is under 255 characters you can send it as a single item in an SIO, but if it is greater than 255 you will need to send it as multiple strings, making sure that the final string has a \n character at the end.

KVM_IP_Address

The KVM_IP_Address command allows you to set the KVM IP address.

RTP_Stream

The RTP Stream input is used to set the rtp address, using the full rtp string in the format rtp://

Example

rtp://10.10.215.123

Custom Command

The Custom Command input can be used to send a command that isn't built in to the driver. Care needs to be taken to make sure the command you are sending is valid as this will simply pass through whatever you present directly to the device. The command can be entered directly as it is, there is no need to add carriage returns or any other characters.

Dynamic IP Address

The Dynamic IP Address input can be used to set the IP address at runtime. By default the parameter IP Address will be used, but if you update this signal it will be used for the next connection. Please note, there will be no immediate change, the new address will only be used on the rising edge of Connect.

Digital Outputs

Connected

The Connected signal will be high when the module is enabled and low when its not.

Play_Live_FB

The Play_Live_FB signal will be high when the devices playback mode is set to live and low when its not.

Play_Local_FB

The Play_Local_FB signal will be high when the devices playback mode is set to local and low when its not.

Mute_FB

The Mute_FB signal will be high when the device is muted and low when its unmuted.

HDMI_FB

The HDMI_FB signal will be high when the HDMI port is enabled and low when it is not.

HDMI_Connection_FB

The HDMI_Connection_FB signal will be high when the HDMI port has an active connection and low when its does not.

KVM_Enable_FB

The KVM_Enable_FB signal will be high when the KVM function is active and low when its not.

USB_Enable_FB

The USB_Enable_FB signal will be high when the USB connection is enabled and low when its not.

Analog Outputs

Output_Stream_FB

The Output_Stream_FB contains the value of the currently selected stream.

Audio_Stream_FB

The Audio_Stream_FB contains the value of the currently selected audio stream

Playlist_FB

The Playlist_FB contains the current playlist number

LineOut_Left_FB

The LineOut_Left_FB contains the current line level out for the left channel.

LineOut_Right_FB

The LineOut_Right_FB The Line_Out_R_FB contains the current line level out for the right channel.

String Outputs

Model

The Model signal contains the model of the connected device.

Device_Name

The Device_Name signal contains the name of the connected device.

MAC_Addr

The MAC_Addr signal contains the mac address of the connected device.

Web_Version

The Web_Version signal contains the version of the web interface software for the connected device.

Firmware

The Firmware signal contains the version of firmware for the connected device.

Input_Resolution

The Input_Resolution signal contains the current input resolution of the connected device.