

Atomic LED - Maintenance Schedule

Maintenance schedule vers. 1.0.0 - Level 1

Part description	Total lamp hours																			
	500 hrs	1000 hrs	1500 hrs	2000 hrs	2500 hrs	3000 hrs	3500 hrs	4000 hrs	4500 hrs	5000 hrs										
Front Lens 1)				C				C												
Back Light LED strips				I				I												
Reflectors																				
LED Lens																				
LED Board																				
B A C K S I D E	SMPS																			
	Base fans	C/SC		C/SC	C/SC	C/SC					C/SC	C/SC	C/SC							
	Filters			C	C	C					C	C	C							
	User Interface																			
	Heat sink																			
	Wireset																			
	Fixture software																			
	Technician skill level	1	2	1	1	1	2	1	1	1	2									

Conditions

Ambient temperature	40°C
Voltage / frequency	Within specified range for the product

Code

I	Inspect
R	Replace
C	Clean
L	Lubricate
A	Adjust
SC	FAN Self clean
U	Update

1)
Only cleaning on the outside.
Important! Do not use concentrated alcohol solutions, abrasive products or solvents to clean the lens. If wiping with a soft, lint-free cloth dampened with distilled water is not effective, dampen the cloth with distilled water containing 20% isopropyl alcohol in solution.