

VDO Face 5 - Maintenance Schedule

Revision A

Months	Maintenance should be done every 3 months or after a rental period																		Note	
	3	6	12	15	18	21	24	27	30	33										
Panel - general																				
Screws back cover	I/A	I/A	I/A	I/A	I/A	I/A	I/A	I/A	I/A	I/A	I/A	I/A	I/A	I/A	I/A	I/A	I/A	I/A	I/A	Tighten screws with 0.5 Nm
Check lock functions	I/A	I/A	I/A	I/A	I/A	I/A	I/A	I/A	I/A	I/A	I/A	I/A	I/A	I/A	I/A	I/A	I/A	I/A	I/A	
Screws locks	I/A	I/A	I/A	I/A	I/A	I/A	I/A	I/A	I/A	I/A	I/A	I/A	I/A	I/A	I/A	I/A	I/A	I/A	I/A	Tighten screw with 1 Nm
Gaskets around connectors	I/C	I/C	I/C	I/C	I/C	I/C	I/C	I/C	I/C	I/C	I/C	I/C	I/C	I/C	I/C	I/C	I/C	I/C	I/C	
LED Block - general																				
Gasket around connector	I/C	I/C	I/C	I/C	I/C	I/C	I/C	I/C	I/C	I/C	I/C	I/C	I/C	I/C	I/C	I/C	I/C	I/C	I/C	
Shaders	I/C	I/C	I/C	I/C	I/C	I/C	I/C	I/C	I/C	I/C	I/C	I/C	I/C	I/C	I/C	I/C	I/C	I/C	I/C	Clean according to Note 1)

Legend

Cells with red fill is for certified Martin Technicians only! Failure to comply will result in warranty void.

Cells without fill can be performed by end-users.

Conditions

Ambient temperature	Max 50°C (122° F) Min -20°C (-4° F)
Daily Lamp on Hours	8
Voltage / frequency	Within specified range for the product

1)

Do not use abrasive, caustic or solvent-based products for cleaning, as they can cause surface damage.

To clean a VDO Face 5™ panel:

1. Vacuum or gently blow away dust and loose particles from the panel with low-pressure compressed air.

2. Wipe the outside of the LED modules with a soft, lint-free cloth dampened with a solution of water and detergent or auto shampoo. Apply gentle pressure only.

Ignoring service and maintenance schedules will result in warranty void!

Code

I	Inspect
R	Replace
C	Clean
L	Lubricate
A	Adjust
U	Update