

N1000/N2000 Series

Direct Control API



An SVSi system is comprised of Encoders, Decoders, and other available accessories including Digital Video Recording (DVR) solutions, Window Processing (WP) units, and Audio Transceivers (ATRs). The system allows you to distribute HD video and audio across a Gigabit Ethernet network. The Encoders accept DVI-I sources including HDMI, DVI-D, VGA, and Component through the use of passive adapters and analog audio using a balanced or unbalanced Phoenix connection. The Decoders have DVI-D video output ports and will support digital audio (with DVI-to-HDMI cable or adapter). Options for Power over Ethernet (PoE), analog audio, and more depend on the version of Decoder used. Please verify hardware capabilities needed prior to ordering.

Legacy hardware and N-Series hardware is backwards-compatible (which allows both legacy and N-Series products to be used within the same system as needed).

Each device is controllable via TCP/IP direct socket using device IP addresses and port 50002. Port 50002 supports a single connection at one time and rejects all other connection attempts until the established connection is closed.

Refer to this document to find the commands needed for your application. This document applies to the N1000 and N2000 Series of Encoders and Decoders.

Send commands with a semi-colon or Carriage Return Line Feed (CRLF) following the command. Refer to the examples given below.

Command Examples

To change the stream on a Decoder (perform a video switch), use the command:

```
set:212;
```

or

```
set:<stream#>
```

Using the Onboard RS-232 Port

Serial communications are enabled on port 50004. If a persistent socket is maintained, this becomes a bi-directional serial port to control the attached source or display. There are no commands to send a serial string. Instead, simply send the manufacturer's serial string to port 50004. Any response returns via port 50004 as well. To set the serial port settings, use N-Able (SVSi's free device management software) or a product from the N-Command series of VoIP Control systems. Similarly to port 50002, this port only supports a single socket connection and rejects all other connection attempts until the open connection is successfully closed.

Getting More Information

This document does not describe controlling an SVSi device when using N-Able or N-Command. For more information, please refer to the additional documentation found at the following link: <http://svsiav.com/support/resources/>.

To find direct control commands for other devices (other than N1000 and N2000 Encoders and Decoders) please visit our support page at the following link: <http://svsiav.com/support/resources/programming-resources/>.

Decoders

DEVICE STATUS				
Command	Description	Response	Example	Notes
getStatus	Returns with current status of device.	Current status of device	getStatus; or ?;	Refer to the return packet information in the table Decoder Response on page 3 .

VIDEO/AUDIO SWITCH				
Command	Description	Response	Example	Notes
set	Switches video streams.	Current status of device	set:1;	If Decoder is set to Audio Follows Video this will also switch the audio stream. If set to a non-existent stream (like stream 0) then Decoder will revert to local play content.
seta	Switches audio streams.	Current status of device	seta:1;	

AUDIO CONTROLS				
Command	Description	Response	Example	Notes
mute	Disables audio output.	Current status of device	mute;	This affects both analog outputs (if available) and digital outputs.
unmute	Enables audio output.	Current status of device	unmute;	
lovol	Changes audio output level.	Current status of device	lovol:50;	Range in Percentage 0 - 100%
lovolleft	Changes audio output level left channel.	Current status of device	lovolleft:50;	Range in Percentage 0 - 100%
lovolright	Changes audio output level right channel.	Current status of device	lovolright:50;	Range in Percentage 0 - 100%

MODE CHANGE				
Command	Description	Response	Example	Notes
live	Changes mode to live play.	Current status of device	live;	Only needed if Decoder has been commanded to local play.
local	Changes mode to local play.	Current status of device	local:4;	8 playlists available, values: 1 - 8
dviOff	Disables video output.	Current status of device	dviOff;	
dviOn	Enables video output.	Current status of device	dviOn;	On by default. Only needed if DVI port has already been disabled.

SCALER CONTROLS				
Command	Description	Response	Example	Notes
scalerenable	Enables scaled output.	Current status of device	scalerenable;	Enables scaler to selected output resolution.
scalerdisable	Disables scaled output.	Current status of device	scalerdisable;	Disables scaler. Video output is source resolution.
modeset	Changes output resolution.	Current status of device	modeset:1080p60;	Modes = auto 1080p59.94 1080p60 480p 480p59.94 720p59.94 720p60 Note: auto = scale to display native resolution
cropref	Changes crop location for Decoder output.	Current status of device	cropref:5,50,720,720;	Based on a 1080p pixel size (1920 x 1080): cropref:xUL, yUL, xLR, yLR

EXTERNAL DEVICE CONTROL				
Command	Description	Response	Example	Notes
sendir	Activates a stored IR command on Decoder.	Current status of device	sendir:commandname;	Command name is name created during commissioning project. If command is saved as PON - then command would be: sendir:PON.

EXTERNAL DEVICE CONTROL (CONTINUED)

Command	Description	Response	Example	Notes
sendirraw:<commanddata>;	Sends IR command with Pronto Code.	Current status of device	sendirraw: 0000 006C 0022 0000 015B 00AD 0016 0016 0016 0016 0016 0041 0016 0016 0016 0016 0016 0016 0016 0016 0016 0041 0016 0041 0016 0016 0016 0016 0016 0041 0016 0041 0016 0041 0016 0041 0016 0016 0016 0041 0016 0041 0016 0041 0016 0016 0016 0016 0016 0016 0016 0016 0016 0016 0016 0016 0016 0016 0016 0016 0016 0041 0016 0041 0016 0041 0016 0041 0016 0041 0016 0622;	Sends Pronto Hex Code to attached IR port. No need to pre-store command in device.
sender:<commandname>;	Executes serial command stored in unit's software. Recall is by saved name.	Current status of device	sender:play;	The <commandname> is case and space sensitive. We recommend saving the commands as lowercase, all one word (for example, playpause).
serSet	Configures serial port to desired settings.	Current status of device	serSet:9600,8,none,1;	serSet:baudrate,databits,parity,stop. Reference N-Able or other control software for valid settings. Only needed if serial port has not been initialized with N-Command software.

DECODER RESPONSE

Response	Description	Notes
Response packet is sent as a confirmation to all commands. Additional information may be contained before the response packet. It is recommended when decoding response data to search for the field required and then output the data accordingly. All fields are separated by "x0D".		
SVSi_RXGEN2:N222A0400 00463	Device type and serial number	
NAME:Adam 2K	Name of device	Serial string with name (255 character max)
MAC:00:19:0B:00:0D:BE	Mac address of device	
IP:169.254.34.55	IP address of device	
NM:255.255.0.0	Subnet mask of device	
GW:169.254.1.1	Gateway of device	
IPTRIAL:0	IP in trial mode	SVSi software specific
IPMODE:AUTO IP	IP mode of device	DHCP Static Auto IP
SWVER:9/29/2014	Software version running on device	SVSi software specific
WEBVER:1412023780	Web version running on device	SVSi software specific
UPDATE:0	SVSi software specific	SVSi software specific
UPDTRY:0	SVSi software specific	SVSi software specific
UPDFAILED:0	SVSi software specific	SVSi software specific
MEDIAPORT0:on	Multicast traffic control	on = multicast can leave port off = no multicast can leave port
MEDIAPORT1:off	Multicast traffic control	on = multicast can leave port off = no multicast can leave port
DIVASEN:0	SVSi software specific	SVSi software specific
DIVASIP:0.0.0.0	SVSi software specific	SVSi software specific
MASSEREN:0	Serial master enable	0 = disabled 1 = enabled
MASSERIP:0.0.0.0	IP of serial slave	IP address 0.0.0.0 = unassigned
discoveryIP:239.254.12.16	SVSi software specific	SVSi software specific
enableDiscoveryPackets:on	SVSi software specific	SVSi software specific
discoveryIntervalSec:10	SVSi software specific	SVSi software specific
discoveryPort:50019	SVSi software specific	SVSi software specific
BAUD:115200	Serial port settings	
SNUMB:8	Serial port settings	
SPAR:none	Serial port settings	
SP2S:1	Serial port settings	
MODE:720p60.mode	Scaler output mode	All modes are followed by .mode. Modes = auto 1080p59.94 1080p60 480p 480p59.94 720p59.94 720p60
PORTSD1:no	P1 disabled completely	yes = deactivated (no traffic) no = active and working
GARP:0	Gratuitous interval	SVSi software specific

DECODER RESPONSE (CONTINUED)		
Response	Description	Notes
GARPINT:50	Interval setting	SVSi software specific
UNSOLST:1	Unsolicited status (to SVSi controllers)	SVSi software specific
UNSOLSTINT:10	Interval setting	SVSi software specific
ID:0	SVSi software specific	SVSi software specific
DVICEVTDLY:1	N-Act connect event delay time in seconds	up to 24 hours (measured in seconds)
DVIDEVTDLY:1	N-Act disconnect event delay time in seconds	up to 24 hours (measured in seconds)
USERMCMODE:off	Customize multicast address?	on = multicast will be customized off = multicast will NOT be customized
USERMCIP:0.0.0.0	Custom multicast address (USERMCMODE must be on)	multicast address
LPDISKSPACE:83268608	Available disk space for local play storage	SVSi software specific
SERSRCIP:0.0.0.0	Serial source IP	
SEROPEN:0	Serial port open?	0 = closed 1 = open
SLCK:0	Setting lock	0 = unlocked 1 = locked
HTTPS:0	Use secure network connection	0 = off 1 = on
LINEOUTVOL_L:35	Current line out volume - left channel	0 - 100%
LINEOUTVOL_R:35	Current line out volume - right channel	0 - 100%
MUTE:0	Mute status	0 = audio enabled 1 = audio disabled
STREAM:3	Current video stream	Numeric value
STREAMAUDIO:0	Current audio stream	Numeric value 0 = follow video
SCALERBYPASS:no	Scaler status	yes = scaler IS disabled no = scaler IS enabled
PLAYMODE:local	Current playmode	local live
PLAYLIST:1	Current local playlist	Number 1 - 8
HDMIAUDIO:on	HDMI audio settings	auto on off
LIVEAUDIOLP:off	Play stream audio in local play	on = use stream audio off = use local play audio
YUVOUT:auto	Color space settings	auto on = YUV output off = normal output
GEN1COMP:auto	Compatibility mode with SVSi V-Series Encoders	auto on off
SIMDVIDET:on	Simplified DVI detect	on off
FRAMEHOLD:off	Hold last frame if stream lost	on = hold last frame off = display local play
VIDOFFNOSTRM:off	Disabled DVI port on loss of stream	on = disable DVI on loss of stream off = display local play
NEGSYNC:off	Invert DVI sync	on = switch sync off = normal sync
DVIOFF:off	DVI port state	on = DVI disabled off = outputting video
DVISTATUS:disconnected	DVI status	connected = monitor on/detected disconnected = monitor off/detached
INPUTRES:1280x720	Current incoming resolution	
FPGAVER:8/1/2014	SVSi software specific	SVSi software specific
STRMCAST:0	SVSi software specific	
NEEDVSTRM:0	Not receiving current assigned stream	0 = receiving stream 1 = not receiving stream
ND_MRRQ:172.20.87.80	Network diagnostic tools	
ND_MRRQ_CHG:0	Network diagnostic tools	
ND_A_DROP:341	Network diagnostic tools	
ND_A_DROP1S:0	Network diagnostic tools	
ND_V_DROP:4448	Network diagnostic tools	
ND_V_DROP1S:0	Network diagnostic tools	
ND_F_DROP:0	Network diagnostic tools	
ND_F_DROP1S:0	Network diagnostic tools	
DM_D_EN:auto	Multichannel audio down mix settings	SVSi software specific
DM_D_IEN:off	Multichannel audio down mix settings	SVSi software specific
DM_A_EN:on	Multichannel audio down mix settings	SVSi software specific
DM_A_SRC:0	Multichannel audio down mix settings	SVSi software specific
DM_CGAIN:42	Multichannel audio down mix settings	SVSi software specific

DECODER RESPONSE (CONTINUED)

Response	Description	Notes
DM_FGAIN:60	Multichannel audio down mix settings	SVSi software specific
DM_SLGAIN:-42	Multichannel audio down mix settings	SVSi software specific
DM_SRGAIN:42	Multichannel audio down mix settings	SVSi software specific
FCPC:on	Force copy protection	on auto

Encoders

DEVICE STATUS

Command	Description	Response	Example	Notes
getStatus	Returns with current status of device.	Current status of device	getStatus; or ?;	Refer to return packet information in the table Encoder Response on page 6 .

AUDIO STATUS

Command	Description	Response	Example	Notes
mute	Disables audio output.	Current status of device	mute;	This affects both analog outputs (if available) and digital outputs.
unmute	Enables audio output.	Current status of device	unmute;	

MODE CHANGE

Command	Description	Response	Example	Notes
live	Changes mode to live play.	Current status of device	live;	Only needed if Decoder has been commanded to local play.
local	Changes mode to host play.	Current status of device	local:4;	8 playlists available, values: 1 - 8
txdisable	Disables all broadcasts from Encoder.	Current status of device	txdisable;	Any Decoders currently viewing stream will transition to local play.
txenable	Enables broadcast from Encoder.	Current status of device	txenable;	

SCALER CONTROLS

Command	Description	Response	Example	Notes
scalerenable	Enables scaled output.	Current status of device	scalerenable;	Enables scaler. Content will be broadcast as selected output resolution.
scalerdisable	Disables scaled output.	Current status of device	scalerdisable;	Disables scaler.
modeset	Changes output resolution.	Current status of device	modeset:1080p60;	Modes = 1080p59.94 1080p60 480p 480p59.94 720p59.94 720p60

EXTERNAL DEVICE CONTROL

Command	Description	Response	Example	Notes
sendirraw:<commanddata>;	Sends IR command with Pronto Code.	Current status of device	sendirraw: 0000 006C 0022 0000 015B 00AD 0016 0016 0016 0016 0016 0041 0016 0016 0016 0016 0016 0016 0016 0016 0016 0041 0016 0041 0016 0016 0016 0016 0016 0041 0016 0041 0016 0041 0016 0041 0016 0016 0016 0041 0016 0041 0016 0041 0016 0016 0016 0016 0016 0016 0016 0016 0016 0016 0016 0016 0016 0016 0016 0016 0016 0041 0016 0041 0016 0041 0016 0041 0016 0041 0016 0622;	Sends Pronto Hex Code to attached IR port. No need to pre-store command in device.
sender:<commandname>;	Executes serial command stored in unit's software. Recall is by saved name.	Current status of device	sender:play;	The <commandname> is case and space sensitive. We recommend saving the commands as lowercase, all one word (for example, playpause).
serSet	Configures serial port to desired settings.	Current status of device	serSet:9600,8,none,1;	serSet:baudrate,databits,parity,stop. Reference N-Able or other control software for valid settings. Only needed if serial port has not been initialized with N-Command software.

ENCODER RESPONSE		
Response	Description	Notes
SVSi_TXGEN2:N212A030000006	Device type and serial number	
NAME:Adam N-Enc	Device name	
MAC:00:19:0B:00:08:86	Device MAC	
IP:169.254.119.168	Device IP	
NM:255.255.0.0	Device subnet mask	
GW:169.254.1.1	Device gateway	
IPTRIAL:0	IP trial mode (during resetting of IP addresses)	SVSi software specific
IPMODE:AUTO IP	IP mode of device	DHCP Static Auto IP
SWVER:6/21/2014	Software version	SVSi software specific
WEBVER:1371820321	Web interface version	SVSi software specific
UPDATE:0	Update flags for SVSi updater	SVSi software specific
UPDTRY:0	Update flags for SVSi updater	SVSi software specific
UPDFAILED:0	Update flags for SVSi updater	SVSi software specific
MEDIAPORT0:on	P0 multicast status	on = multicast can leave port off = no multicast can leave port
MEDIAPORT1:on	P1 multicast status	on = multicast can leave port off = no multicast can leave port
DIVASEN:0	SVSi software specific	SVSi software specific
DIVASIP:0.0.0.0	SVSi software specific	SVSi software specific
MASSEREN:0	Serial master enable	0 = disabled 1 = enabled
MASSERIP:0.0.0.0	IP of serial slave	IP address 0.0.0.0 = unassigned
discoveryIP:239.254.12.16	SVSi software specific	SVSi software specific
enableDiscoveryPackets:on	SVSi software specific	SVSi software specific
discoveryIntervalSec:10	SVSi software specific	SVSi software specific
discoveryPort:50019	SVSi software specific	SVSi software specific
BAUD:9600	Serial port settings	
SNUMB:8	Serial port settings	
SPAR:none	Serial port settings	
SP2S:1	Serial port settings	
MODE:720p59.94.mode	Scaler output mode	All modes are followed by .mode. Modes = auto 1080p59.94 1080p60 480p 480p59.94 720p59.94 720p60
PORTSD1:no	P1 disabled completely	yes = deactivated (no traffic) no = active and working
GARP:0	Gratuitous ARP enabled	N-Command specific
GARPINT:50	Interval for ARP	N-Command specific
UNSOLST:1	Unsolicited status enabled	N-Command specific
UNSOLSTINT:10	Interval for unsolicited status	N-Command specific
ID:0	SVSi software specific	SVSi software specific
DVICEVTDLY:1	N-Act connect event delay time in seconds	up to 24 hours (measured in seconds)
DVIDEVTDL:1	N-Act disconnect event delay time in seconds	up to 24 hours (measured in seconds)
USERMCMODE:off	Customize multicast address?	on = multicast will be customized off = multicast will NOT be customized
USERMCIP:0.0.0.0	Custom multicast address (USERMCMODE must be on)	multicast address
LPDISKSPACE:95454208	Host play disk space	SVSi software specific
SERSRCIP:0.0.0.0	Serial source IP	
SEROPEN:0	Serial port open?	0 = closed 1 = open
SLCK:0	Setting lock	0 = unlocked 1 = locked
HTTPS:0	Use secure network connection	0 = off 1 = on
LINEIN:bal	Line in is balanced or unbalanced	se = unbalanced audio bal = balanced audio
MUTE:0	Mute status	0 = audio enabled 1 = muted
STREAM:134	Broadcast stream of Encoder	
SAMPLE:44100	Audio sample rate	
AUDIODELAY:21000	Audio delay in milliseconds	SVSi software specific (not currently used)
CLRSPCCOR:auto	Color space correction	auto on off Note: Should be auto.
HPNONSUP:off	Host play in supported mode	SVSi software specific

ENCODER RESPONSE (CONTINUED)

Response	Description	Notes
HDMIAUDIO:auto	HDMI audio state	auto on off
UNCOMP:off	Uncompressed mode	SVSi software specific <i>Note: In most systems, should be off.</i>
LIVEAUDIOHP:off	Use live audio source while in HP mode	on off (SVSi software specific)
EXTREMEQUAL:off	Extreme quality mode	SVSi software specific
QUALITY:100	Compression level	SVSi software specific
MOTQUAL:100	Motion level	SVSi software specific
SCALERBYPASS:yes	Scaler enabled/disabled	yes = disabled no = enabled
PLAYMODE:live	Device mode	live local
PLAYLIST:1	Host playlist to be displayed	Playlists are 1 - 8
OUTBW:1034160	Output bandwidth in bytes per second	SVSi software specific
OUTBWMBS: 7.8	Output bandwidth in megabytes per second	SVSi software specific
DVIINPUT:connected	Source status	connected = source is available disconnected = no source
DVIPASSTHR:disconnected	Passthrough port	connected = monitor detected disconnected = no monitor
PTHDMIAUDIO:on	Passthrough HDMI audio	on off
PTYUVOUT:auto	Passthrough color correction	auto on off
PTSIMDVIDET:off	Simplified DVI detect for passthrough port	SVSi software specific
PTNEGSYNC:off	SVSi software specific	SVSi software specific
AGAINL:0	Volume control - left channel (gain only)	0 - 100%
AGAINR:0	Volume control - right channel (gain only)	0 - 100%
CPC:allowed	HDCP status	allowed disallowed
CISPROT:not-protected	Current source protected?	protected not-protected
INPUTRES:1280x720	Current incoming resolution	
FPGAVER:6/20/2014	SVSi software specific	SVSi software specific
GEN1OUTPUTMODE:off	Compatibility with V-Series	on off
SOGWindow:16	Current sync on green sensitivity	0-63
N2121CM:1	Compatibility with N2121	0 = disabled 1 = enabled
CRYPT:0	Current encryption status	0 = not encrypted 1 = encrypted

IT SIMPLY WORKS

Distribution | Switching | Recording | Windowing | Wall Processing | Control

© Southern Vision Systems, Inc. • 256. 461.7143 • www.svsiv.com

SVSi is a trademark of Southern Vision Systems, Inc. in the United States and other countries.

All other brand names, product names and trademarks are the property of their respective owners. Certain trademarks, registered trademarks, and trade names may be used to refer to either the entities claiming the marks and names or their products. SVSi disclaims any interest in the marks and names of others.

800DOCNSCPREV2.0



Made in the USA.

